

# Operation & Maintenance Manual

**GAS GENERATOR ENGINE**

**GE12TIC**


















## FOREWORD

This manual is designed to serve as a reference for HD Hyundai Infracore customers and distributors who wish to gain basic product knowledge on HD Hyundai Infracore **GE12TIC** natural gas engines.

These economical and high-performance natural gas engines (6 cylinders, 4 strokes, in-line type) have been so designed and manufactured to be used for the generator application. They meet all the requirements such as low noise, fuel economy, high engine speed and durability.

To maintain the engine in optimum condition and retain maximum performance for a long time, **CORRECT OPERATION** and **PROPER MAINTENANCE** are essential.

In this manual, the following symbols are used to indicate the type of service operations to be performed.

	Removal		Adjustment
	Installation		Cleaning
	Disassembly		Pay close attention-Important
	Reassembly		Tighten to specified torque
	Align the marks		Use special tools of manufacturer's
	Directional Indication		Lubricate with oil
	Inspection		Lubricate with grease
	Measurement		

During engine maintenance, please observe following instructions to prevent environmental damage;

- Take old oil to an old oil disposal point only.
- Ensure without fail that oil will not get into the sea or rivers and canals or the ground.
- Treat undiluted anti-corrosion agents, antifreeze agents, filter element and cartridges as special waste.
- The regulations of the relevant local authorities are to be observed for the disposal of spent coolants and special waste.

If you have any question or recommendation in connection with this manual, please do not hesitate to contact our head office, dealers or authorized service shops near by your location for any services.

For the last, the content of this maintenance instruction may be changed without notice for some quality improvement. Thank you.

- \* Items exempted from warranty coverage
  - Malfunctions resulting from failing to comply with the proper handling instructions, regular inspections, and machine storage techniques specified in the user manual
  - Malfunctions resulting from failing to have the machine repaired at a designated dealer or center, or resulting from the use of non-genuine parts
  - Malfunctions resulting from unauthorized modifications, changes, or external hardware
  - Malfunctions resulting from incorrect operation by the user, delayed repairs, accidents, and natural disasters
  
- \* The contents of this operation and maintenance manual are the exclusive property of HD Hyundai Infracore. Any unauthorized reproduction, printing and distribution thereof are strictly prohibited.

# CONTENTS

<b>1. Safety Regulations &amp; Engine Specifications</b> .....	<b>1</b>
1.1. General notes .....	1
1.2. Handle natural gas safety .....	1
1.3. General information .....	7
1.4. Engine assembly .....	9
<b>2. Technical Information</b> .....	<b>12</b>
2.1. Engine model and serial number .....	12
2.2. Engine Characteristic .....	12
2.3. Diagnosis and remedy .....	29
2.4. Engine inspection .....	39
<b>3. Disassembly and Reassembly of Major Components</b> .....	<b>41</b>
3.1. Disassembly .....	41
3.2. Inspection .....	53
3.3. Reassembly .....	72
3.4. Starting and trial operation .....	94
3.5. Speed controller setting .....	96
3.6. Electrical system .....	101
3.7. Speed controller .....	104
3.8. Ignition controller .....	106
3.9. Ignition control module .....	109
<b>4. Commissioning and Operation</b> .....	<b>114</b>
4.1. Operation preparation .....	114
4.2. Breaking-in .....	114
4.3. Inspections after starting .....	116
4.4. Operation in winter time .....	117
4.5. Tuning the engine .....	117
4.6. Maintenance and care .....	118
4.7. Cooling system .....	120
4.8. Adjustment of valve clearance .....	122
4.9. Tightening the cylinder head bolts .....	125
4.10. Cylinder compression pressure .....	126
4.11. Belts .....	127

**5. Maintenance of Major Components ..... 129**

- 5.1. Cooling system ..... 129
- 5.2. Lubricating system ..... 133
- 5.3. Turbocharger ..... 137
- 5.4. Air intake system (Optional) ..... 145

# 1. Safety Regulations & Engine Specifications

## 1.1. General notes

Day-to-day use of power engines and the service products necessary for running them presents no problems if the persons occupied with their operation, maintenance and care are given suitable training and think as they work.

This summary is a compilation of the most important regulations. These are broken down into main sections which contain the information necessary for preventing injury to persons, damage to property and pollution. In addition to these regulations those dictated by the type of engine and its site are to be observed also.



### **IMPORTANT:**

**If despite all precautions, an accident occurs, in particular through contact with caustic acids, fuel penetrating the skin, scalding from oil, antifreeze being splashed in the eyes etc, consult a doctor immediately.**

## 1.2. Handle natural gas safety

Natural gas is highly flammable and explosive and may be extremely cold. The following cautions must be taken to avoid personal injury or engine damage.

- Do not smoke when installing or servicing the engine or fuel system.
- Installation or servicing of natural gas equipment must only be conducted in well ventilated, natural gas compatible areas. Do not install or service equipment in an enclosed area where ignition sources are present without ensuring that an undetected gas leak may be safely vented without being ignited.
- Do not vent natural gas or permit leaks inside an enclosed area.  
Bleed natural gas lines before installing or servicing any component connected to the fuel lines.




### 1.2.1. Avoid heating near pressurized fluid lines

- Wear welding goggles and gloves when welding or using an acetylene torch.
- Insure a that metal shield separated the acetylene and oxygen which must be chained to a cart.
- Do not weld or heat areas near fuel tanks or fuel lines.



### 1.2.2. Venting an operable engine to relieve natural gas pressure

- To avoid personal injury an operable natural gas engine must be kept in a well ventilated area away from open flames and sparks.
- If the engine can run, use the following venting procedure to relive the natural gas pressure downstream of the shutoff valve.



- 1) Shut off manual valves on natural gas supply lines and main shutoff valve on natural gas fuel supply line.
- 2) Start engine and run until it stalls due to fuel starvation.
- 3) Check to make sure gauge pressure at point on the natural gas fuel line to be vented has been reduced to zero. If not, repeat step 1) Then repeat step 2).
- 4) Disconnect engine batteries using switch in battery compartment or by disconnecting battery ground cable.
- 5) Slightly loosen the NG fuel line fitting to be serviced in a well ventilated area to allow any remaining gas to vent.
- 6) Completely open the fitting that was slightly opened and allow to vent in a well ventilated area.

### 1.2.3. During commissioning, starting and operation



- This is the safety alert symbol. When you see this symbol in this manual, be alert to the potential for personal injury.



- Carefully read all safety message in this manual and on your engine safety signs. Be sure new equipment components and repair parts include the current safety signs.



- Avoid possible injury or death from vehicle runaway. Do not start engine by shorting across starter terminals. Vehicle will start in gear if normal circuitry is bypassed. Start engine only from operator's seat with transmission in neutral or park.



- Prevent fires by keeping machine clean of accumulated trash, grease, fuel and debris.
- When the engine is running, do not get too close to the rotating parts.



- Do not touch the engine with bare hands when it is warm from operation risk of burns.



- Exhaust gases are toxic. If it is necessary to run an engine in an enclosed area, remove the exhaust gases from the area with an exhaust pipe extension. If you do not have an exhaust pipe extension, open the doors and get outside air into the area.



- Keep vicinity of engine free of oil and grease. Accidents caused by slipping can have serious consequences.

#### 1.2.4. During maintenance and care



- Always carry out maintenance work when the engine is switched off. If the engine has to be maintained while it is running, e.g. changing the elements of change-over filters, remember that there is a risk of scalding. Do not get too close to rotating parts.
- Change the oil when the engine is warm from operation.



#### **CAUTION:**

**There is a rise of burns and scalding. Do not touch oil drain plug or oil filters with bare hands.**

- Take into account the amount of oil in the sump. Use a vessel of sufficient size to ensure that the oil will not overflow.
- Open the coolant circuit only when the engine has cooled down. If opening while the engine is still warm is unavoidable, comply with the instructions in the chapter "Maintenance and Care".
- Neither tighten up nor open pipes and hoses (lube oil circuit, coolant circuit and any additional hydraulic oil circuit) during the operation. The fluids which flow out can cause injury.



- Fuel is inflammable. Do not smoke or use naked lights in its vicinity.
- When using compressed air, e.g. for cleaning the radiator, wear goggles.



- Keep service products (anti-freeze) only in containers which can not be confused with drinks containers.
- Comply with the manufacturer's instructions when handling batteries.



#### **CAUTION:**

**Accumulator acid is toxic and caustic. Battery gases are explosive.**

### 1.2.5. When carrying out checking, setting and repair work

- Checking, setting and repair work must be carried out by authorized personnel only.
- Use only tools which are in satisfactory condition. Worn open-end wrench slip, which could lead to injury.
- When the engine is hanging on a crane, no-one must be allowed to stand or pass under it. Keep lifting gear in good condition.
- When working on parts which contain asbestos, comply with the notes at the end of this chapter.
- When working on the electrical system disconnect the battery earth cable first. Connect it up again last in prevent short circuits.



### 1.2.6. To prevent damage to engine and premature wear

- (1) Never demand more of the engine than it was designed to yield for its intended purpose.
- (2) If faults occur, find the cause immediately and have it eliminated in order to prevent more serious of damage.
- (3) Use only genuine HD Hyundai Infracore spare parts. HD Hyundai Infracore will accept no responsibility for damage resulting from the installation of other parts which are supposedly "just as good".
- (4) In addition to the above, note the following points.
  - Never let the engine run when dry, i.e. without lube oil or coolant.
  - Use only HD Hyundai Infracore approved service products (engine oil, anti-freeze and anticorrosion agent).
  - Pay attention to cleanliness. The Natural gas must be free of water. See "Maintenance and care"
  - Have the engine maintained at the specified intervals.
  - Do not switch off the engine immediately when it is warm, but let it run without load for about 5 minutes so that temperature equalization can take place.
  - Never put cold coolant into an overheated engine. See "Maintenance and care".
  - Do not add so much engine oil that the oil level rises above the max. marking on the dipstick. Do not exceed the maximum permissible tilt of the engine. Serious damage to the engine may result if these instructions are not adhered to.
  - Always ensure that the testing and monitoring equipment (for battery charge, oil pressure, coolant temperature) function satisfactorily.
  - Comply with instructions for operation of the alternator. See "Commissioning and operation".
  - Do not let the raw water pump run dry, If there is a risk of frost, drain the pump when the engine is switched off.
- (5) Keep no-load operation to a minimum. During no-load operation combustion chamber temperatures drop to the point where fuel does not burn completely, causing slobbering and white smoke. Always have some load connected when the gen set is run for long periods.

### 1.2.7. To prevent pollution

#### (1) Engine oil, filter elements, fuel filters

- Take old oil only to an oil collection point.
- Take strict precautions to ensure that oil does not get into the drains or into the ground. The drinking water supply could be contaminated.
- Filter elements are classed as dangerous waste and must be treated as such.

#### (2) Coolant

- Treat undiluted anti-corrosion agent and / or antifreeze as dangerous waste.
- When disposing of spent coolant comply with the regulations of the relevant local authorities.

#### (3) Cold Start

- The preheat lamp turns on when the key switch is set to "ON." When the preheat lamp goes off, proceed as follows. The pre-heater device activates when the coolant temperature is below 25°C, and the preheating system is automatically adjusted based on the coolant temperature. (The max. preheating time is around 25 seconds) It does not activate when the coolant temperature is over 25°C.



#### **CAUTION:**

**The engine is equipped with a preheating system for enhancing cold start ability.**

- In order to start the engine after the preheat lamp turns off, turn the key switch to the ignition position. When the key switch is turned to the ignition position, the pre-heater plug or air heater runs continuously to make starting the engine easier and reduce white exhaust gas. If the coolant temperature is over 25°C, it is not necessary to operate the pre-heater plug or air heater
- When the engine starts, set the key switch in the ON position. The timer runs for another 5 minutes even after the engine starts to heat the intake air and quickly eliminate white exhaust gas.



#### **CAUTION:**

**Do not run the start motor for over 10 seconds. If the engine still cannot be started after preheating, wait for 30 seconds and then perform preheating again before the second attempt to start the engine.**

### 1.2.8. Notes on safety in handling used engine oil

Prolonged or repeated contact between the skin and any kind of engine oil decreases the skin.

Drying, irritation or inflammation of the skin may therefore occur. Used engine oil also contains dangerous substances which have caused skin cancer in animal experiments. If the basic rules of hygiene and health and safety at work are observed, health risks are not to the expected as a result of handling used engine oil



#### **Health precautions:**

- Avoid prolonged or repeated skin contact with used engine oil.
- Protect your skin by means of suitable agents (creams etc.) or wear protective gloves.
- Clean skin which has been in contact with engine oil.

- Wash thoroughly with soap and water, A nailbrush is an effective aid.
- Certain products make it easier to clean your hands.
- Do not use petrol, Diesel fuel, gas oil, thinners or solvents as washing agents.
- After washing apply a fatty skin cream to the skin.
- Change oil-soaked clothing and shoes.
- Do not put oily rags into your pockets.



**Ensure that used engine oil is disposed of properly.**

**- Engine oil can endanger the water supply -**

For this reason do not let engine oil get into the ground, waterways, the drains or the sewers. Violations are punishable.

Collect and dispose of used engine oil carefully. For information on collection points please contact the seller, the supplier or the local authorities.



**CAUTION:**

**Do not spray high-pressure water directly on the engine. It may damage engine parts, electronic parts, and wiring.**

**1.2.9. General repair instructions**



1. Before performing service operation, disconnect the grounding cable from the battery for reducing the chance of cable damage and burning due to short-circuiting.
2. Use covers for preventing the components from damage or pollution.
3. Engine oil and anti-freeze solution must be handled with reasonable care as they cause paint damage.
4. The use of proper tools and special tools where specified is important to efficient and reliable service operation.
5. Use genuine HD Hyundai Infracore parts necessarily.
6. Used cotter pins, gaskets, O-rings, oil seals, lock washer and self-lock nuts should be discarded and new ones should be prepared for installation as normal function of the parts can not be maintained if these parts are reused.
7. To facilitate proper and smooth reassemble operation, keep disassembled parts neatly in groups. Keeping fixing bolts and nut separate is very important as they vary in hardness and design depending on position of installation.
8. Clean the parts before inspection or reassembly. Also clean oil ports, etc. using compressed air to make certain they are free from restrictions.
9. Lubricate rotating and sliding faces of parts with oil or grease before installation.
10. When necessary, use a sealer on gaskets to prevent leakage.
11. Carefully observe all specifications for bolts and nuts torques.
12. When service operation is completed, make a final check to be sure service has been done property.

### 1.3. General information

#### 1.3.1. Engine Specifications

Items		Engine model	GE12TIC
Engine type			Water-cooled, 4 cycle in-line type Turbo charged & intercooled
Ignition system			Spark ignition
Combustion chamber type			Open dish type
Used fuel			NG (Natural Gas)
Cylinder liner type			Replaceable dry liner
Timing gear system			Gear driven type
No. of piston ring			2 compression ring, 1 oil ring
No. of cylinder-bore x stroke		(mm)	4 - 123 x 155
Total piston displacement		(cc)	11,051
Compression ratio			10.5 : 1
Engine dimension (length x width x height)		(mm)	1,540 x 854 x 1,073
Engine weight		(kg)	910
Rotating direction (from flywheel)			Counter clockwise
Firing order			1 - 5 - 3 - 6 - 2 - 4
Fuel ignition timing (B.T.D.C static)			13° ±1°
Engine control system			Engine speed controller type
Compression pressure		(kg/cm <sup>2</sup> )	16 (at 200 rpm)
Valve clearance (at cold)	Intake valve	(mm)	0.4 ±0.05
	Exhaust valve	(mm)	0.4 ±0.05
Intake valve	Open at		18° (B.T.D.C)
	Close at		34° (A.B.D.C)
Exhaust valve	Open at		46° (B.B.D.C)
	Close at		14° (A.T.D.C)
Lubrication method			Full forced pressure feed type
Oil pump type			Gear type driven by crankshaft
Engine oil pressure	Low idle	(bar)	0.8 ~ 1.4
	High idle	(bar)	3.0 ~ 4.8
Oil filter type			Full-flow, cartridge type
Lubricating oil capacity (max./min.)		(lit)	30/24 (optional : 50/33)
Oil cooler type			Water cooled
Water pump			Gear driven impeller type
Cooling Method			Forced circulation by centrifugal impeller pump
Cooling water capacity (engine only)		(lit)	25
Thermostat type			Wax pallet type (79~94°C)
Alternator voltage – capacity		(V - A)	24 – 45
Starting Motor voltage – output		(V - kW)	24 – 6.0
Fuel system	Carburetor		Impco 200 varifuel carburetor
	Gas regulator		RV61
	Max. inlet pressure		1.0 psi at the engine inlet
	Shut-off valve		Solenoid valve (24VDC)

Items	Engine model	GE12TIC
Ignition system	Spark plug	Woo jin 0.39 ~ 0.40mm air gap
	Ignition controller	Altronic CD-1
	Ignition coil	One coil per cylinder
	Trigger system	Magnetic pick-up sensor and trigger wheel
Turbocharger	Model	HX50
	Type	Water cooled, Exhaust gas driven
	Exhaust temperature	Max : 750°C

\* Specification may be changed without any prior notice for improvement

### 1.3.2. Engine Power

Production tolerance : ±5%

Engine model		Performance		
		Stand by	Prime	Continuous
GE12TIC	50Hz (1,500 rpm)	187 kW (254 PS)	170 kW (231 PS)	155 kW (211 PS)
	60Hz (1,800 rpm)	220 kW (299 PS)	200 kW (272 PS)	180 kW (245 PS)

● kWm : Mechanical engine power in kW, 1kW = 1.36PS


● Test condition

- 1) Power rating acc. to ISO3046/1
- 2) LHV of fuel = 9,640 kcal/Nm<sup>3</sup>
- 3) Stoichiometric
- 4) Charge air temperature after turbocharger  
Ta3 ≤ 40°C
- 5) Coolant temperature at outlet  
Tcw out = 80°C
- 6) Water-cooled turbocharger

## 1.4. Engine assembly

\* The images shown represent the standard model; they do not include all models.


### 1.4.1. Engine sectional view (longitudinal)



EF50M001

- |                   |                        |
|-------------------|------------------------|
| 1. Exhaust valve  | 10. Combustion chamber |
| 2. Intake valve   | 11. Oil pump           |
| 3. Oil filler cap | 12. Crankshaft         |
| 4. Ignition coil  | 13. Oil pan            |
| 5. Valve spring   | 14. Main bearing cap   |
| 6. Tappet         | 15. Connecting rod     |
| 7. Push rod       | 16. Camshaft           |
| 8. Piston pin     | 17. Flywheel housing   |
| 9. Piston         |                        |


### 1.4.2. Engine sectional view (cross)



EGE12TIC180001

- |                     |                        |
|---------------------|------------------------|
| 1. Oil suction pipe | 6. Inter cooler        |
| 2. Oil filter       | 7. Spark plug          |
| 3. Cylinder block   | 8. Rocker arm          |
| 4. Oil cooler       | 9. Cylinder head cover |
| 5. Oil drain pump   | 10. Piston ring        |

### 1.4.3. Engine assembly views




- |                            |                              |
|----------------------------|------------------------------|
| 1. Flywheel housing        | 12. Oil level gauge          |
| 2. Mounting bracket (rear) | 13. Mounting bracket (front) |
| 3. Oil pressure unit       | 14. Trigger wheel            |
| 4. Oil drain pump          | 15. Alternator               |
| 5. Oil filter              | 16. Cooling water pump       |
| 6. Inter cooler            | 17. Crankshaft pulley        |
| 7. Ignition coil           | 18. Exhaust manifold         |
| 8. Intake manifold         | 19. Breather                 |
| 9. Oil cooler              | 20. Starter                  |
| 10. Oil pan                | 21. Exhaust elbow            |
| 11. Ignition controller    | 22. Turbo charger            |

EF5OM003



## 2. Technical Information

### 2.1. Engine model and serial number

- The engine model and serial number is located on the engine as illustrated. These numbers are required when requesting warranty and ordering parts.
- They are also referred to as engine model and serial number because of their location.



- Engine serial No. (GE12TIC)



### 2.2. Engine Characteristic

- The HD Hyundai Infracore **GE12TIC** natural gas engine is an overhead valve, turbo charged, air-to-water charge cooled, electronically controlled engine.

#### 2.2.1. Natural gas


- Spark-ignited by the spark plug.
- Turbocharger with a water cooled bearing-housing.

#### 2.2.2. Natural gas

- Natural gas is a clean burning fuel, and offers a low particulate emission. Natural gas is also a very economical fuel.
- From the gas producing areas in the country, the distribution companies and local utilities from a complex nation-wide-delivery-network that supplies natural gas for home and industry use. The network is highly developed and extended to all major population center in the country.


### 2.2.3. Engine ignition system

- This system changes the general combustion concept of the diesel engine. Specifically, it changes a compression-ignition diesel to a spark-ignited engine. However, this engine is unlike the typical generator engine that has spark plugs.
- The primary difference is this system uses a combustion concept. That is, excess air is mixed in with the combustion system. When combined with a gaseous fuel like natural gas, it allows greatly reduced emissions compared to diesel, plus high efficiencies and excellent high-performance.
- The GE12TIC engine is an integrated package featuring computer-controlled electronic engine system by the engine speed controller. This system controls fuel, ignition and speed, and has engine protection features.




#### 2.2.4. Engine speed controller : ESC

- The Engine Speed Control is designed to provide basic isochronous speed control for gas engines using the Flo-Tech Throttle.
- Engines with mechanical loads and generator loads are handled equally well.



#### 2.2.5. Ignition control module : ICM

- This digital ignition system has been designed for application on nature gas fueled engines.
- This system offers a variety of advanced control, emissions reduction, primary and spark diagnostics, self diagnostic serial communications and engine protection features.



#### 2.2.6. Cylinder block


- The cylinder block is a single piece of alloy cast iron. To increase its stiffness, it is extended to a level below the crankshaft center line. The engine has replaceable dry cylinder liners and individual cylinder heads with struck-in valve seat rings and replaceable valve guides.

#### 2.2.7. Piston, con-rod and crankshaft

- The forged crankshaft is an ingrate type (Counterweight is integrated with crankshaft body). Radial oil seal on crankshaft and flywheel are provided to seal the flywheel housing inside penetrations.
- The con-rods (connecting rods) are die-forged, diagonally split and can be removed through the top of the cylinders together with the pistons. Crankshaft and connecting rods run in steel-backed lead bronze ready to fit type bearings.

## 2.2.8. Engine timing

- Camshaft, oil pump and ignition timing sensor gear are driven by a gear train arranged at the front end.



## 2.2.9. Valves


- The overhead valves are actuated via chilled cast iron tappets, push rods and rocker arms from the camshaft.

## 2.2.10. Lubrication system

- The engine is equipped with force-feed lubrication.

The pressure is produced by a gear pump whose drive gear is in direct mesh with the crankshaft gear at the front end of cylinder block.

- The oil pump draws the oil from the oil sump and delivers it through the oil cooler and oil filter to the main distributor gallery and from there to the main bearings, big-end bearings and camshaft bearings as well as to the small-end bearings and the rocker arms.
- The turbocharger is also connected to the engine lubricating system.  
The cylinder walls and timing gears are splash-lubricated.
- Each cylinder has an oil jet provided for cooling the underside of the pistons. The lube oil is cleaned in a full-flow oil filter.



### 2.2.11. Engine oil




- Check oil level with the oil level gauge and replenish if necessary.
- Check the oil level with the engine cooled. If the engine is warm, allow time for 5 ~ 10 minutes for oil drain into the crankcase before checking oil level. The oil level must be between **Max.** and **Min.** lines on the gauge.

<b>First oil change</b>	<b>After 50hr operation</b>
<b>Every change interval</b>	<b>every 200hr</b> for standard oil pan
	<b>every 500hr</b> for optional oil pan

<b>SAE No.</b>	<b>API No.</b>	<b>Sulfated ash content</b>
15W40	CD/SF or later	Bellow 0.5 %


- Engine oil should be changed at the specified intervals. Also oil in the oil filter cartridge should be changed simultaneously.
- The oil change interval shall be reviewed considering gas composition, actual operating temperature and adjusted by oil analysis at any site.
  - The following low Ash natural gas engine oil is also recommended
  - Engine oil capacity

<b>Engine oil capacity</b>				
<b>Engine model</b>	<b>in Oil pan</b>		<b>Total (lit)</b>	<b>Remark</b>
	<b>Max. (lit)</b>	<b>Min. (lit)</b>		
<b>GE12TIC</b>	30	24	33	Standard
	50	33	53	Optional




### 2.2.12. Exchanging of lubrication oil

- Engine oil and the oil filter are important factors affecting engine life. They affect ease of starting, fuel economy, combustion chamber deposits and engine wear.
- While the oil is still hot, discharge the sump oil by motion oil drain pump lever manually as figure.



- Refill new engine oil to the filler neck on the head cover in accordance with the oil capacity of the engine. Be careful about the mixing of dust or contaminator during the supplement of oil. Then confirm whether the oil level gauge indicates the vicinity of its maximum level.
- For a few minutes, operate the engine at idling in order to circulate oil through lubrication system. Thereafter shut down the engine. After waiting for about 10 minutes measure the quantity of oil and refill the additional oil if necessary.




### 2.2.13. Oil cooler

- An oil cooler is provided between the oil filter and the cylinder block.
- This cooler is a flat tube type with turbulence inserts and operated by the coolant.

### 2.2.14. Oil filter




- Check for oil pressure and oil leaks, and repair or replace the oil filter if necessary.
- Change the oil filter cartridge simultaneously at every replacement of engine oil.



### 2.2.15. Cooling system

- The engine has a liquid-cooling system. The coolant circuit shall be equipped with deaeration line from an engine..
- Depending on the agreed extent of delivery and the design of the engine, the coolant circuit can be equipped with temperature monitors which, in the event of loss of coolant, shut the engine down. But even after shut-down the system, shall allow a system water pump to run at least 3 to 5 minutes.



### 2.2.16. Cooling water

- Regarding the cooling water that is to be used for engine, the soft water not the hard water must be used.
- The engine cooling water can be used diluting it with antifreezing solution 40% and the additive for rust prevention (DCA4) 3 ~ 5 %.
- The density of above solution and additive must be inspected every 500 hours to maintain it properly.



#### NOTE:

The proper density control of antifreezing solution and rust preventing additive will be able to prevent the rusting effectively and maintain the stable quality of engine. For the improper control might give the fatal damage to the cooling water pump and cylinder liners, detail care is needed.

- Since **GE12TIC** cylinder liner is dry type, particularly the cooling water control should be applied thoroughly.

- The density of antifreezing solution and additive for rust prevention is able to be confirmed by the cooling water test kit.  
(Fleetguard CC2602M or HD Hyundai Infracore 65.99901-0038)
- How to use the cooling water test kit
  - (1) When the cooling water temp. of engine is in the range of 10 ~ 55°C, loosen the plug for cooling water discharge and fill the plastic cup about a half.



**NOTE:**

**In taking the cooling water sample, if the water in auxiliary tank were taken, it is hard to measure the accurate density. Take the cooling water sample necessarily loosening the cooling water discharge plug.**

- (2) At the state of a test paper soaked in the sampled water, after taking the paper out through water agitation, shake off the water.
- (3) Wait for about 45 sec. till the color change of test paper.



**NOTE:**

**However, it should not elapse longer than 75 sec, and if it did, the hue would change.**

- (4) Make the numerical value by comparing the test paper which hue has changed with the color list of label on storage bottle.
- (5) By comparing the hue changed into yellowish green or so with the green color indication of test paper storage bottle, confirm the density. (Then, the density indication must be in the hue range of 33% to 50%).
- (6) The brown at the middle of test paper and the lower pink color indication represent the additive state for rust prevention, and the proper range is that the meeting numerical value of brown (vertical) and pink color (horizontal) locates in the range of 0.3 to 0.8 at the color list of label on the test paper storage bottle.
- (7) In case of less than 0.3, replenish the additive for rust prevention (DCA4), and in case of more than 0.8, pour out the cooling water about 50% and then readjust the density after refilling with clean fresh water.


- Amount of Anti-freeze in winter

Ambient Temperature (°C)	Cooling water (%)	Anti-freeze (%)
Over -10	85	15
-10	80	20
-15	73	27
-20	67	33
-25	60	40
-30	56	44
-40	50	50

### 2.2.17. V - belt




- Use a belt of specified dimensions, and replace if damaged, frayed, or deteriorated.
- Check the belt for belt tension. If belt tension is lower than the specified limit, adjust the tension by relocating the alternator. (specified deflection:10~15 mm when pressed down with thumb)



### 2.2.18. Intercooler

- The intercooler is air-gas to water type. The intercooler life and performance depends on the intake air condition greatly. Fouled air pollutes and clogs the air fins of intercooler. As a result of this, the engine output is decreased and engine malfunction is occurred.
- So you always check whether the intake air systems like air filter element are damaged or polluted.



### 2.2.19. Valve clearance adjust procedure



● After letting the #1 cylinder's piston come at the compression top dead center by turning the crankshaft, adjust the valve clearances.



● Loosen the lock nuts of rocker arm adjusting screws and push the feeler gauge of specified value between a rocker arm and a valve stem and adjust the clearance with adjusting screw respectively and then tighten with the lock nut.


● As for the valve clearance, adjust it when in cold, as follow.

Specified Value		Measurement Tolerance	
Intake Valve	Exhaust Valve	Intake Valve	Exhaust Valve
0.4 mm	0.4 mm	±0.05 mm	



● Adjust valve clearance with a feeler gauge and tighten the fixing nuts to specified torque.


Torque	4.4 ±0.45 kg.m
--------	----------------



#### ● Adjusting Sequence of Valve Clearance (1 Type)

- By cranking the engine, let #6 cylinder's valves overlap.
- In time, adjust the valve clearance corresponding to “ ⇐⇒ ” of lower lists.  
Rotating the crankshaft by one revolution, let #1 cylinder's valves overlap.
- Adjust the valve clearance corresponding to “ → ” of lower lists.
- After reinsuring the valve clearances, retighten if necessary.

● No. 1 Cylinder is located at the side where flywheel was installed.



● **Adjusting Sequence of Valve Clearance (2 Type)**

1 Type is the conventional and simple method, but if you have some problem to adjust your engine, please try 2 type sequence. This is a precision method, but it takes more times.

Valve overlapping on cylinder (Intake & Exhaust valve)	1	5	3	6	2	4
Adjusting valves on cylinder (Intake & Exhaust valve)	6	2	4	1	5	3

**2.2.20. Spark plug**




- Remove spark plug. Clean threads by hand with brush and solvent.
- Clean any deposits from electrode and Inspect insulator area
- Measure the spark plug distance at electrode position.(A)
- Replace spark plug if necessary.


	Standard
Distance (A)	0.39 ~ 0.40mm




- Install spark plug

Torque	2.04 ~ 4.08 kg.m
--------	------------------






### 2.2.21. Cylinder compression pressure




- Stop the engine after warming up, and take out spark plug.



- Install the special tool (compression gauge adapter) at the spark plug hole and connect the compression pressure gauge there.

Standard value	16 kg/cm <sup>2</sup> over
Limit value	13 kg/cm <sup>2</sup>
Difference between each cylinder	Within $\pm 10\%$




- ◆ Condition : Water temperature 20°C,  
Engine rotation 200 rpm

### 2.2.22. Battery




- Inspect for any leakage of electrolytic solution owing to battery crack, and replace the battery in case of poor condition.
- Inspect for amount of electrolytic solution, and replenish if insufficient.
- Measure the gravity of electrolytic solution, if less than specified value (1.12 ~ 1.28), replenish.



### 2.2.23. Turbocharger


- The exhaust gases of the engine are passed through the turbine rotor of the turbocharger. Air compressor impeller mounted on the same shaft draws in fresh air and delivers it at a higher pressure to the cylinders.
- The turbocharger is naturally aircooled. Lubrication of the main bearing is by oil under pressure from the engine lubricating system.




## 2.2.24. Alternator

### ● Alternator (24Vx45A)

The alternator is fitted with integral silicon rectifiers. A transistorized regulator mounted on the alternator body interior limits the alternator voltage. The alternator should not be operated except with the regulator and battery connected in circuit to avoid damage to the rectifier and regulator.




The alternator is maintenance-free, nevertheless, it must be protected against dust and, above all, against moisture and water.




Operate the alternator according to the instructions given in the chapter.

### 2.2.25. Starting motor

The sliding-gear starter motor is flanged to the rear of the flywheel housing on the left-hand side. As parts of every engine overhaul, the starter pinion and ring gear should be cleaned with a brush dipped in fuel and then a coat of grease should be applied again.




**Always protect starter motor against moisture.**




**WARNING:**


**Always disconnect the battery earth cable before starting work on the electrical system. Connect up the earth cable last, as there is otherwise a risk of short-circuits.**





## 2.3. Diagnosis and remedy


- The following description summarizes the probable cause of and remedy for general failure by item.
- Immediate countermeasures should be taken before a failure is inflamed if any symptom is detected.




















Condition	Causes	Remedies
5) Engine noisy	For noises arise compositely such as rotating parts, lapping parts etc., there is necessity to search the cause of noises accurately.	
(1) Crankshaft	<ul style="list-style-type: none"> <li>● As the wear of bearing or crankshaft progress, the oil clearances increase.</li> <li>● Lopsided wear of crankshaft</li> <li>● Oil supply insufficient due to oil passage clogging</li> <li>● Stuck bearing</li> </ul>	<p>Replace bearing &amp; grind crankshaft</p> <p>Grind or replace Clean oil passage</p> <p>Replace bearing &amp; Grind</p>
(2) Connecting rod and Connecting rod bearing	<ul style="list-style-type: none"> <li>● Lopsided wear of con rod bearing</li> <li>● Lopsided wear of crank pin</li> <li>● Connecting rod distortion</li> <li>● Stuck bearing</li> <li>● Oil supply insufficiency as clogging at oil passage progresses</li> </ul>	<p>Replace bearing</p> <p>Grind crankshaft Repair or replace Replace &amp; grind crankshaft Clean oil passage</p>
(3) Piston, piston pin & piston ring	<ul style="list-style-type: none"> <li>● Piston clearance increase as the wear of piston and piston ring progresses</li> <li>● Wear of piston or piston pin</li> <li>● Piston stuck</li> <li>● Piston insertion poor</li> <li>● Piston ring damaged</li> </ul>	<p>Replace piston &amp; piston ring</p> <p>Replace Replace piston Replace piston Replace piston</p>
(4) Others	<ul style="list-style-type: none"> <li>● Wear of crankshaft, thrust bearing</li> <li>● Camshaft end play increased</li> <li>● Idle gear end play increased</li> <li>● Timing gear backlash excessive</li> <li>● Valve clearance excessive</li> <li>● Abnormal wear of tappet, cam</li> <li>● Turbocharger inner part damaged</li> </ul>	<p>Replace thrust bearing</p> <p>Replace thrust plate</p> <p>Replace thrust washer Repair or replace</p> <p>Adjust valve clearance Replace tappet, cam</p> <p>Repair or replace</p>

Condition	Causes	Remedies
6) Oil Consumption Excessive (1) Oil level elevated	<ul style="list-style-type: none"> <li>● Clearance between cylinder liner &amp; piston</li> <li>● Wear of piston ring, ring groove</li> <li>● Piston ring's damage, stick, wear</li> <li>● Piston ring opening's disposition improper</li> <li>● Piston skirt part damaged or abnormal wear</li> <li>● Oil ring's oil return hole clogged</li> <li>● Oil ring's contact poor</li> </ul>	Replace  Replace piston, piston ring  Replace piston ring  Correct position  Replace piston  Replace piston ring  Replace piston ring
(2) Oil level lowered	<ul style="list-style-type: none"> <li>● Looseness of valve stem &amp; guide</li> <li>● Wear of valve stem seal</li> <li>● Cylinder head gasket's leak</li> </ul>	Replace in set  Replace seal Replace gasket
(3) Oil leak	<ul style="list-style-type: none"> <li>● Looseness of connection parts</li> <li>● Various parts' packing poor</li> <li>● Oil seal poor</li> </ul>	Replace gasket, repair  Replace packing Replace oil seal

## 2.4. Engine inspection

### 2.4.1. Stopping engine

- Cut off the main circuit breaker of the generator control panel. After checking the engine for any unusual condition at the idling speed, then press the stop button to stop the engine.

### 2.4.2. General engine inspection cycle

- In order to insure maximum, trouble-free engine performance at all times, regular inspection, adjustment and maintenance are vital.
  - Daily inspections in below figure should be checked every day.
  - The following maintenance details should be executed thoroughly at regular intervals.

○ : Check & adjust ● : Replace

Inspection Item		Daily	Every 50hrs	Every 500hrs	Every 700hrs	Every 1500hrs	Every 3000hrs	Remark
<b>Cooling System</b>	Check for leakage(hoses, clamp)	○						
	Check the water level	○						
	Adjust the V-belt tension	○						
	Change the coolant water							● 1 year
<b>Lubrication System</b>	Check for leakage	○						
	Check the oil level gauge	○						
	Change the lubricating oil		● 1st	●				Every 500hr
	Replace the oil filter cartridge		● 1st	●				Every 500hr
<b>Intake &amp; Exhaust System</b>	Check the leakage for intercooler (hoses, clamp)	○				●		
	Check the air cleaner indicator	○						
	Clean the air cleaner element and/or repair			○ Clean		●		
	Clean the exhaust system						○	
<b>Fuel System</b>	Check the leakage fuel line	○						
	Check the fuel mixer							○ 1 year
	Check the throttle body							○ 1 year
	Check the speed controller							○ 1 year
	Check the gas pressure regulator							○ 1 year
<b>Ignition system</b>	Check the state of ignition timing							When necessary
	Check the spark plug				●			
	Check the ignition cable							● 1 year
	Check the ignition coil							○ 1 year
	Check the sensors(ignition or timing)	○						
<b>Engine Adjust</b>	Check the state of exhaust gas	○						
	Check the exhaust gas pressure							When necessary
	Check the battery charging	○						
	Check the compression pressure							When necessary
	Adjust Intake/Exhaust valve clearance		● 1st		●			

### **2.4.3. Use of original parts for repair and replacement**

- For engine is being mechanically harmonized with many parts, only when the original parts that the manufacture recommends to use is used, the engine trouble would be preventively maintained and capable to keep up the maximum performances.
- For the analogous parts not the original parts are poor in qualities and gives ill performances, it may rather bring early engine failure

## 3. Disassembly and Reassembly of Major Components

### 3.1. Disassembly


#### 3.1.1. General precautions



- Maintenance operation should be carried out in a bright and clean place.
- Before disassembly, provide parts racks for storage of various tools and disassembled parts.
- Arrange the disassembled parts in the disassembly sequence and use care to prevent any damage to them..


#### 3.1.2. Oil level gauge

- Pull out the oil level gauge.




#### 3.1.3. Cooling water

- Remove the drain plug at the cylinder block and drain out the cooling water into a container.




#### 3.1.4. Engine oil

- Turn the valve opening and then move the oil drain pump lever as figure by hand, and let engine oil discharge into the prepared vessel




### 3.1.5. Engine speed controller: ESC

- Disconnect the harness and the various sensors.




### 3.1.6. Ignition control module (ICM)

- Disconnect the harness and the various sensors.
- Loosen the fixing bolt, then disassemble the ignition control module(ICM).




### 3.1.7. Ignition coil & gas pressure regulator

- Remove the high voltage cables by hand from each cylinder head.
- Remove the gas pressure regulator fixing bolts and then tear down the gas pressure regulator and other parts.




### 3.1.8. Fuel mixer

- Remove the air cleaner from fuel mixer.
- Remove the fuel mixer and air pipe from the turbo charger.




### 3.1.9. Turbo charger

- Remove the oil supply pipe and oil return pipe between the turbo charger and the cylinder block.
- Unclamp the rubber hose connected the intercooler and air pipe.
- Unscrew the turbo charger fixing nuts and take off the turbo charger from the exhaust manifold




### 3.1.10. Intercooler

- Tear down the various hoses and air pipes from the inter cooler.
- Remove the intercooler fixing bolts and tear it down.



### 3.1.11. V-belt

- Loosen the tension adjusting nut installed on the alternator bracket, and take off the alternator belt.




### 3.1.12. Breather

- Loosen the clamp screw to remove the rubber hose.


### 3.1.13. Starter

- Unscrew the starter fixing bolts, then disassemble the starter.




### 3.1.14. Thermostat

- Remove the by-pass pipe connected to the water pump, unscrew the thermostat fixing bolts, then disassemble the thermostat housing and thermostat.
- Disassemble the water pipe by unscrewing the bolts and nuts installed on the cylinder head.



### 3.1.15. Intake manifold

- Loosen the intake manifold fixing bolts, then disassemble the intake manifold.




### 3.1.16. Exhaust manifold

- Release the exhaust manifold fixing bolts, disassemble the exhaust manifold, then remove the heat shield and gasket.




**CAUTION:**  
Be careful to remove the exhaust manifold. It is very heavy.




### 3.1.17. Water pump

- Remove the water pipe connected to the expansion tank.
- Remove the water pipe and hoses connected to the water pump.
- Unscrew the water pump fixing bolts and remove the water pump.




### 3.1.18. Oil filter

- Using a filter remover wrench, remove the oil filter cartridge.
- Remove the pipe connected to the oil cooler.
- Loosen the oil filter fixing bolts and disassemble the oil filter head from the cylinder block.



### 3.1.19. Vibration damper


- Unscrew the pulley fixing bolts and disassemble the pulley-vibration damper assembly.
- Unscrew the vibration damper fixing bolts and disassemble the damper from the pulley.



### 3.1.20. Timing gear case cover




- Disassemble the oil seal using an oil seal removing jig.
- Remove the cover fixing bolts and disassemble the cover from the timing gear case.





### 3.1.21. Idle gear

- Unscrew the idle gear fixing bolts and disassemble the thrust washer and idle gear.
- Disassemble the idle gear pin using a rubber hammer to prevent damage to them.




### 3.1.22. Timing trigger drive

- Disassemble the ignition timing sensor, trigger wheel and coupling.
- Unscrew the timing trigger drive assembly fixing bolts and remove the timing trigger drive assembly in which the shaft, gear, bearing and housing are put together.




### 3.1.23. Cylinder head cover

- Unscrew the cover fixing bolts and disassemble the cover.
- Keep the bolts in an assembly state so that the packing and washers may not be lost, and keep the cover packing as assembled with the cover.



### 3.1.24. Rocker arm assembly


- Unscrew the rocker arm bracket bolts and remove the rocker arm assembly.
- Take off the snap rings to remove the washers and rocker arm, then unscrew the bracket fixing bolts to take off the bracket and springs.
- Take out the push rods.



### 3.1.25. Ignition coil and spark plug

- Loosen the ignition coil fixing nut, then remove the ignition coil.
- Remove the spark plug using socket tool.

Socket tool	Hex. head :16mm (5/8 inch)
-------------	-------------------------------




### 3.1.26. Spark plug tube



- Install the plug screw (M25x1.0) on the spark plug tube, then insert the bar through bottom cylinder head and lightly tap it to remove.




**CAUTION:**  
Do not perform disassembly operation unless coolant, gas, etc. leak out.



### 3.1.27. Cylinder head


- Unscrew the cylinder head fixing bolts and take off the cylinder head.
- Remove the cylinder head gasket.



### 3.1.28. Valve and valve stem seal





- Compress the valve spring retainer using a jig and take off the valve cotter pins.
- Disassemble the valve springs and retainers.
- Take off the valves.
- Remove and discard the valve stem seal using a general tool as it should not be re-used.




### 3.1.29. Oil cooler

- Remove the water pipe connected to the water pump.
- Remove the oil pipe connected to the cylinder block.
- Unscrew the oil cooler cover fixing bolts and disassemble the oil cooler assembly from the cylinder block.
- Unscrew the oil cooler fixing bolts and remove the oil cooler from the oil cooler cover.




### 3.1.30. Oil pan

- Stand the engine with the flywheel housing facing the bottom.
- Release the oil pan fixing bolts, remove the oil pan.




### 3.1.31. Oil pump and oil pipe

- Unscrew the oil suction pipe bracket bolts, releasing the pipe fixing bolts, then disassemble the oil suction pipe assembly.
- Disassemble the oil pipe feeding oil from the oil pump to the cylinder block.
- Unscrew the oil pump fixing bolts and disassemble the oil pump.




### 3.1.32. Relief valve

- Disassemble the relief valve.




### 3.1.33. Piston and connection rod

- Disassemble the pistons by two cylinders while turning the crankshaft.
- Unscrew the connecting rod fixing bolts and take off the pistons and connecting rods in the direction of piston.






- Remove the piston pin snap rings, take off the piston pin, then disconnect the connecting rod from the piston.




- Disassemble the piston rings using ring pliers.
- Use care not to interchange the disassembled parts and keep them in the sequence of cylinder No.




### 3.1.34. Cylinder liner

- Disassemble the cylinder liner using a liner puller.



### 3.1.35. Flywheel


- Position the engine so that the head installing surface of the cylinder block faces down.
- Unscrew the flywheel fixing bolts and fit a dowel pin.
- Install flywheel disassembling bolts in the bolt holes machined on the flywheel, and disassemble the flywheel.



### 3.1.36. Oil seal




- Take off the rear oil seal using an oil seal disassembling jig.
- If only the inside guide ring is removed, use a special tool to take off the outside seal.




### 3.1.37. Flywheel housing

- Loosen the housing fixing bolts disassemble the flywheel housing.




### 3.1.38. Camshaft and tappet

- Remove the camshaft gear.
- Take off the camshaft gear thrust washer.
- Take out the camshaft using care not to damage the camshaft.
- Slide out the tappets by hand.




### 3.1.39. Crankshaft gear and oil pump idle gear

- Loosen the socket head bolts and take out the oil pump idle gear.
- Use a puller to remove the crankshaft gear.




### 3.1.40. Timing gear case

- Unscrew the case fixing bolts and disassemble the timing gear case.



### 3.1.41. Crankshaft

- Remove the bolts from bearing caps.
- Remove the main bearing cap fixing bolts in the order of assembling. (Remove them in the same way of the cylinder head bolts.)
- Maintain the removed bearing caps in the order of cylinders.
- Temporarily install the bolts at the both side of crankshaft, and lift the shaft with a rope.




#### Notes :

**Do not mingle with the metal bearings and bearing caps randomly. To prevent mixing, temporarily assemble the metal bearings to the corresponding bearing caps in turn.**

### 3.1.42. Oil spray nozzle

- Unscrew the fixing bolt and remove the oil spray nozzles.



## 3.2. Inspection

### 3.2.1. Cylinder block



- 1) Clean the cylinder block thoroughly and make a visual inspection for cracks or damage.
- 2) Replace if cracked or severely damaged, and correct if slightly damaged.
- 3) Check oil and water flow lines for restriction or corrosion.
- 4) Make a hydraulic test to check for any cracks or air leaks.

(Hydraulic test) :

Stop up each outlet port of water/oil passages in the cylinder block, apply air pressure of about 4kg/cm<sup>2</sup> against the inlet ports, then immerse the cylinder block in water for about 1 minute to check any leaks. (Water temperature: 70°C)

### 3.2.2. Cylinder head

#### 1) Inspection




- Carefully remove carbon from the lower face of the cylinder head using nonmetallic material to prevent scratching of the valve seat faces.
- Check the entire cylinder head for very fine cracks or damage invisible to ordinary sight using a hydraulic tester or a magnetic flaw detector.

#### 2) Distortion at the lower face




- Measure the amount of distortion using a straight edge and a feeler gauge at six positions (A ~ F) as shown in the right figure.
- If the measured value exceeds the standard value, retrace the head with grinding paper of fine grain size to correct such defect.
- If the measured value exceeds the maximum allowable limit, replace the cylinder head.



#### < Lower face warpage and height >

	Standard	Limit
Warpage	0.2 mm or less	0.3 mm
Thickness : t (reference)	114.95 ~ 115.0 mm	113.9 mm



### 3) Flatness



- Measure flatness of the intake/exhaust manifolds fitting surfaces on the cylinder head using a straight edge and a feeler gauge.

Standard	Limit
0.05 mm	0.2 mm

### 4) Hydraulic test



- Hydraulic test method for the cylinder head is same as that for cylinder block.

#### 3.2.3. Spark plug



- Remove spark plug. Clean threads by hand with brush and solvent.




- Clean any deposits from electrode and inspect insulator area



- Measure the spark plug distance at electrode position.(A)
- Correct or replace the spark plug if necessary.


Standard	0.38 ~ 0.40 mm
----------	----------------



- Insert the spark plug into cylinder head and measure distance(B)

Torque	3.6 ~ 4.1 kg.m
--------	----------------

Standard	3.38 ~ 3.76 mm
----------	----------------



### 3.2.4. Valve and valve guide

#### 1) Valve




- Clean the valves with clean diesel oil, then inspect them as follows:

- **Valve stem outer diameter**



Measure the valve stem outer diameter at 3 positions. (top, middle, and bottom) If the amount of wear is beyond the limit, replace the valve.

Dimension Description	Standard	Limit
Intake valve stem	$\phi 10.950 \sim \phi 10.970 \text{ mm}$	$\phi 10.87 \text{ mm}$
Exhaust valve stem	$\phi 10.935 \sim \phi 10.955 \text{ mm}$	$\phi 10.84 \text{ mm}$



- **Valve seat contacting faces**




Check the valve seat contacting faces for scratches or wear, and correct the faces with grinding paper as necessary. Replace if severely damaged.

- **Valve head thickness**



Measure the valve head thickness, and replace the valve if the measured value is beyond the limit.

Dimension Description	Standard	Limit
Intake valve	1.5 mm	1 mm or less
Exhaust valve	1.5 mm	0.9 mm or less




## 2) Valve guide

- Install the valve into the valve guide and measure the clearance between them by valve movement.
- If the clearance is excessive, measure the valve and replace either the valve or the valve guide, whichever worn more.



### ● Valve stem end play

Dimension Description	Standard	Limit
Intake valve	0.04 ~ 0.07 mm	0.2 mm
Exhaust valve	0.06 ~ 0.09 mm	0.25 mm



- Install the valve into the cylinder head valve guide, then check and see if it is centered with the valve seat using a special tool.



## 3) Valve seat


### ● Contacting face amount



Measure the contacting face between the intake valve seat and exhaust valve seat for valve seat wear, and replace if the measured value exceeds the specified limit.



- Install the valve into the valve seat on the cylinder head, and check the amount of depression of the valve from the lower portion of the cylinder head using a dial gauge.



### ● Valve recession

Dimension Description	Standard	Limit
Intake & Exhaust	0 ~ 0.03 mm	0.55 mm

- If the amount of depression is beyond the specified limit, replace the valve seat.

- For removal of the valve seat, apply arc welding work to two points of valve seat insert, and pull out the valve seat insert with inner extractor.




- Undercool a new valve seat with dry ice for about 2 hours and press the valve seat insert into position in the cylinder head using a special tool (bench press).

- When replacing valve guide and seat, work simultaneously by special tools.



- Apply valve lapping compound to the valve head seating face on the valve seat and lap the valve seat by turning it until it is seated in position, then wipe out the lapping compound.



#### 4) Valve spring




- **Visual check**

Visually check the exterior of the valve springs for damage, and replace if necessary.

- **Functional check**

- Measure free length and spring tension with a valve spring tester.
- (Refer to appendix)*
- Measure the spring inclination with a square.
- Compare the measured value with the standard value to determine whether to replace or repair.



	Standard	Limit
Valve spring Inclination	1.0 mm	2.0 mm

### 3.2.5. Rocker arm shaft assembly

#### 1) Rocker arm shaft


##### ● Rocker arm shaft run-out



Place the rocker arm shaft on two V blocks and inspect the shaft for bend using a dial gauge.

If the amount of this run-out is small, press the shaft with a bench press to correct the run-out. Replace the shaft if the measured value exceeds the limit.

Limit	0.2 mm
-------	--------




##### ● Rocker arm shaft diameter



With an outside micrometer, measure the rocker arm shaft diameter at the point where the rocker arms have been installed.

Replace the rocker arm if the amount of wear is beyond the specified limit.

Standard	Limit
$\phi 23.978 - \phi 23.959$ mm	$\phi 23.75$ mm



#### 2) Rocker arm

##### ● Visual check



Visually check the face of the rocker arm in contact with the valve stem end for scores and step wear. If the wear is small, correct it with an oil stone or grinding paper of fine grain size.

Rocker arm with a considerable amount of step wear should be replaced.


● **Diameter of the rocker arm bushing**



Measure the inside diameter of the rocker arm bushing with an inside micrometer or vernier calipers, and compare the measured values with the rocker arm shaft diameter. If the clearance exceeds the limit, replace either bushing or shaft, whichever worn more.

<Clearance>

Standard	Limit
0.020 ~ 0.093 mm	0.2 mm



3) **Tappet and push rod**

● **Clearance**




Measure the clearance of the tappet and tappet holes of the cylinder block. If the value is beyond the specified limit, replace tappets.

Standard	Limit
0.035 ~ 0.077 mm	0.15 mm

● **Visual check of tappet**



Visually check the face of the tappets in contact with the cam for pitting, scores or cracks, and replace if severely damaged. If the amount of cracks or pitting is small, correct with an oil stone or grinding paper.




● **Outside diameter**



With an outside micrometer, measure the tappet outside diameter if the measured value is beyond the limit, replace tappets.

Tappet diameter	$\phi 19.944 \sim \phi 19.965$ mm
-----------------	-----------------------------------

Standard	Limit
0.035 ~ 0.077 mm	0.15 mm




EDM2061I

● **Push rod run-out**



Use a feeler gauge to measure the push rod run-out. Roll the push rod along a smooth flat surface as shown in the figure.

Limit	0.3 mm or less
-------	----------------



Feeler gauge

EA0M4073

**3.2.6. Camshaft**


1) **Cam**

● **Cam lobe height**



Use a micrometer to measure the cam lobe height and journal diameter. If the measured number is less than the specified limit, the camshaft must be replaced.

		Standard	Limit
Cam lobe height (C)	Intake	50.50 ~ 50.70 mm	50.30 mm
	Exhaust	50.25 ~ 50.45 mm	50.10 mm
Cam journal diameter (A,B)		$\phi 59.86 \sim \phi 59.88$ mm	$\phi 59.56$ mm



EA0M4062

● **Cam surface**



Inspect the cam face for scratch or damage.


Slight step wear or damage on the cam face may be corrected with oil stone or oiled grinding paper. But, replace if severely damaged.

2) **Camshaft**

● **Clearance between camshaft journal and camshaft bush**



- With an outside micrometer, measure the camshaft journal diameter.
- Measure the inside diameter of the camshaft bushing on the cylinder block using a cylinder bore indicator, and compare the measured value with the camshaft outside diameter to determine the clearance.



<Clearance>


Standard	Limit
0.050 ~ 0.128 mm	0.2 mm

- Replace the bushing if the measured value is beyond the specified limit.

● **Run-out**



Support the camshaft on two V blocks and check for run-out using a dial indicator. Correct or replace the camshaft if the amount of run-out is beyond the value indicating need for servicing.




Standard	Limit
0.05 mm	0.2 mm

### 3) Camshaft end play



- Push the thrust plate toward the cam gear.
- With a feeler gauge, measure the clearance between the thrust plate and camshaft journal.
- If the end play is excessive, replace the thrust plate.

Standard	Limit
0.13 ~ 0.27 mm	0.30 mm



### 3.2.7. Crankshaft

#### 1) Defect check




- Visually check the crankshaft journal and crank pins for scores or cracks.
- Using a magnetic particle test and color check, inspect the crankshaft for cracks, and replace the crankshaft which has cracks.

#### 2) Wear




- With an outside micrometer measure the diameter of the crankshaft journals and pins in the directions as shown, and compare the measured values to determine the amount of wear.



- If the amount of wear is beyond the limit, have the crankshaft ground and install undersize bearings. However, if the amount of wear is within the limit, you can correct the wear using an oil stone or oiled grinding paper of fine grain size. (Be sure to use grinding paper which has been immersed in oil.)

	Standard	Limit
Journal diameter	$\phi 95.966 \sim \phi 95.988$ mm	$\phi 94.966$ mm
Pin diameter	$\phi 82.966 \sim \phi 82.988$ mm	$\phi 81.966$ mm



< Undersize bearings available >



- ▶ Standard
- ▶ 0.25 (Inside diameter is 0.25 mm lesser than the standard size.)
- ▶ 0.50 (Inside diameter is 0.50 mm lesser than the standard size.)
- ▶ 0.75 (Inside diameter is 0.75 mm lesser than the standard size.)
- ▶ 1.00 (Inside diameter is 1.00 mm lesser than the standard size.)

Undersize bearings are available in 4 different sizes as indicated above, and the crankshaft can be reground to the above sizes.




**Note:**

When regrounding the crankshaft as described below, the fillet section 'R' should be finished correctly. Avoid sharp corners or insufficient fillet.

< Standard values of "R" >

- ① Crankshaft Pin "R" :  $4.5_{-0.2}^0$
- ② Crankshaft journal "R" :  $4_{-0.2}^0$




**1) Crankshaft run-out**



- Support the crankshaft on V blocks.
- Turn the crankshaft with a dial indicator placed on the surface plate and take the amount of crankshaft run-out.

Standard	Limit
0.05 mm	0.1 mm



**3.2.8. Crankshaft bearing and connection rod bearing**

**1) Visual check**



Visually check the crankshaft bearing and connecting rod bearing for scores, uneven wear or damage.

**2) Oil clearance between crankshaft and bearing.**

● **Main bearing clearance**




Install the main bearing in the cylinder block, tighten the bearing cap to specified torque, then measure the inside diameter.



Torque	30 kg.m
--------	---------

Standard dia.	$\phi 96.06 \sim \phi 96.108$ mm
---------------	----------------------------------



**CAUTION:**

**Main bearing bolts can only be reused up to 3 times; reusing them more than that may cause damage.**



Compare the two values obtained through measurement of main bearing inside diameter with the outside diameters of crankshaft journals to determine the oil clearance.

**< Main bearing oil clearance >**

Standard	Limit
0.072 ~ 0.142 mm	0.25 mm




● **Connecting rod bearing clearance**

Install the connecting rod bearing in the connecting rod bearing cap, tighten the connecting rod cap bolts to the specified torque, then measure the inside diameter.

Torque	1st Step	8 ±0.4 kgf·m
	2nd Step	60° ±3°

Standard	φ83.02 ~ φ83.092 mm
----------	---------------------




**CAUTION:**

**Connecting rod bearing bolts can only be reused up to 3 times; reusing them more than that may cause damage.**

Compare the two values obtained through measurement of connecting rod bearing inside diameter with the outside diameters of crankshaft pins to determine the oil clearance.

Standard	Limit
0.049 ~ 0.119 mm	0.20 mm





- If the clearance deviates from the specified range, have the crankshaft journals and pins ground and install undersize bearings.

### 3) Bearing spread and crush

#### ● Inspection



Check to see that the bearing requires a considerable amount of finger pressure at reassembly operation.




#### ● Crankshaft bearing crush



Install the bearing and cap in the cylinder block, retighten the bolts to specified torque, unscrew out one bolt completely, then measure the clearance between the bearing cap and cylinder block using a feeler gauge.

Standard	0.15 ~ 0.25 mm
----------	----------------




● Connecting rod bearing crush



Install the bearing and cap in the connecting rod big end, retighten the bolts to specified torque, unscrew out one bolt completely, then measure the clearance between the bearing cap and connecting rod big end using a feeler gauge.

Standard	0.086 ~ 0.116 mm
----------	------------------




4) Crankshaft end play



- Assemble the crankshaft to the cylinder block.
- With a dial gauge, measure crankshaft end play.

Standard	Limit
0.15 ~ 0.325 mm	0.5 mm



3.2.9. Piston

1) Visual check




Visually check the pistons for cracks, scuff or wear, paying particular attention to the ring groove.

2) Clearance between the piston and cylinder liner



- With an outside micrometer, measure the piston outside diameter at a point 18mm away from the lower end of piston skirt in a direction at a right angle to the piston pin hole.


Standard	$\phi 122.854 \sim \phi 122.886$ mm
----------	-------------------------------------





- Using a cylinder bore gauge, measure cylinder liner inside diameter at 3 points (cylinder top ring contacting face, middle, and oil ring contacting face on BDC) in a direction at an angle of 45°. Take the mean value with the largest and smallest values excepted.

Standard	Limit
$\phi 123 \sim \phi 123.023 \text{ mm}$	$\phi 123.223 \text{ mm}$



- The clearance is computed by subtracting the piston outside diameter from the cylinder liner inside diameter. Replace either piston or cylinder liner, whichever damaged more, if the clearance is beyond the specified limit.

< Clearance between piston and liner >

Standard	0.114 ~ 0.169 mm
----------	------------------

### 3.2.10. Piston rings

#### 1) Visual check



- Replace the piston rings with new ones if detected worn or broken when the engine is overhauled.


#### 2) Piston ring gap

- Insert the piston ring into the upper portion of the cylinder liner bore so that it is held at a right angle to the cylinder liner wall.



- Measure the piston ring gap with a feeler gauge.

	Standard	Limit
Top ring	0.30 ~ 0.45 mm	1.5 mm
2nd ring	0.35 ~ 0.50 mm	1.5 mm
Oil ring	0.30 ~ 0.50 mm	1.5 mm




- Replace piston rings with new ones if the gap is beyond the limit

### 3) Piston ring side clearance



- Fit the compression ring and oil ring in the piston ring groove.
- With a feeler gauge, measure side clearance of each ring, and replace either the ring or piston if the measured value is beyond the specified limit.

	Standard	Limit
Top ring	-	-
2nd ring	0.07 ~ 0.102 mm	0.15 mm
Oil ring	0.05 ~ 0.085 mm	0.15 mm



### 4) Piston ring tension



- With a tension tester, measure piston ring tension. Replace the piston ring if the measured value is beyond the limit.

	Standard
Top ring	2.27 ~ 3.41 kg
2nd ring	2.0 ~ 3.0 kg
Oil ring	4.03 ~ 5.57 kg


## 3.2.11. Piston pin

### 1) Wear



- Measure the amount of wear on the piston pin at the points as shown. If the measured values are beyond the limit (0.005 mm or greater), replace the pin.

Standard	Limit
$\phi 44.995 \sim \phi 45.0 \text{ mm}$	$\phi 44.990 \text{ mm or less}$




## 2) Clearance



- Measure the clearance between the piston pin and connecting rod bushing, and replace either of them, whichever damaged more, if the measured value is beyond the limit.

Limit	0.011 mm
-------	----------



## 3) Condition check



- Check the engaged condition of the piston and piston pin. If it is possible to force the pin into the piston heated with piston heater, the piston is normal.



- When replacing the piston, be sure to replace the piston pin together.

## 3.2.12. Connecting rod

### 1) Distorsion




- Check the connecting rod for distortion. As shown in the figure below, install the connecting rod to the connecting rod tester, and check for distortion using a feeler gauge. If the connecting rod is found distorted, never re-use it but replace with a new one.

### 2) Holes alignment (parallelism)



- Measure the alignment of the connecting rod small bushing holes with connecting rod big end hole. At this time also, use both connecting rod tester and feeler gauge.

Standard	Limit
0.05 mm	0.1 mm or less



### 3) Wear



- Assemble the connecting rod to the crankshaft and measure connecting rod big end side clearance using a feeler gauge.
- Assemble the connecting rod to the piston and measure connecting rod small end side clearance.
- If the measured values are beyond the limit, replace the connecting rod.

Limit	0.5 mm
-------	--------

### 3.3. Reassembly

#### 3.3.1. General precautions



- Wash clean all the disassembled parts, particularly oil and water ports, using compressed air, then check that they are free from restrictions.
- Arrange the general and special tools in order for engine assembly operation.
- To wet each sliding part, prepare the clean engine oil.
- Prepare service materials such as sealant, gaskets, etc.
- Discard used gaskets, seal rings, and consumable parts, and replace with new ones.
- Apply only the specified torque for bolts in the specified tightening order and avoid over-tightening.
- Be sure to check that all the engine parts operate smoothly after being reassembled.
- Check the bolts for looseness after preliminary reassembly.
- After completing the engine reassembly operation, check if there is missing parts or shortage of parts.
- Keep your hands clean during the working.

#### 3.3.2. Cylinder block


- Cover the floor of the workshop with wood plate or thick paper to prevent damage to the cylinder head and place the cylinder block with the head fitting surface facing downward.

#### 3.3.3. Oil spray nozzle



- Tighten and assemble the oil spray nozzle flange with fixing bolts using the spray nozzle jig.

Torque	1.0 ±0.1 kg.m
--------	---------------




### 3.3.4. Tappet and camshaft



- Undercool a new bush with dry ice for about 2 hours and press it into position in the cylinder block using a bench press. After the pressing operation, measure the inside diameter of the cam bush to check if it is not deformed.




- Apply engine oil to the entire face of the tappets and slide them into the tappet holes on the cylinder block.



- Wet the cam bush inside diameter and camshaft with oil, and carefully assemble them while turning the camshaft.




- Check to see that the camshaft rotates smoothly.




### 3.3.5. Crankshaft




- Install the main bearing machined with two holes in the cylinder block so that the key is aligned with the key groove, then apply oil to the bearing surface.




- Heat the crankshaft gear for at least 10 minutes to 120°C, then apply sealant (Loctite # 641) to the inside wall of the heated crankshaft gear evenly before inserting it to the end of crankshaft.




- Semi-tighten a bolt at both sides of the crankshaft, apply engine oil to journals and pins, then assemble the crankshaft with the cylinder block by tightening the fixing bolts.



- Install the oiled thrust washers with the oil groove facing outward.




- Install the bearing and thrust washers to the bearing cap and apply oil to the bearing and thrust washers.





- Install the bearing cap by matching the cylinder block No. with the bearing cap No.




- Tighten in tightening sequence to specified torque..

Torque	30 kg.m
--------	---------



**CAUTION:**

**Main bearing bolts can only be reused up to 3 times; reusing them more than that may cause damage.**



- After semi-tightening both bolts evenly tighten them diagonally to about 15kg.m for the first stage and 25kg.m for the second stage respectively, then tighten them completely to the specified torque using a torque wrench.
- Tighten the bearing cap in the sequence of 4-3-5-2-6-1-7.




- Check to see that the assembled crankshaft turns smoothly.

**3.3.6. Flywheel housing**

- Temporarily install the guide bar on the cylinder block.
- Apply gasket to the cylinder block.
- Using the dowel pin and guide bar, install the flywheel housing and tighten the fixing bolts in a diagonal sequence to specified torque.




Torque	11.2 ±1.6 kg.m
--------	----------------



### 3.3.7. Rear oil seal



- Apply lubricating oil to the outside of the oil seal and flywheel housing inside diameter and fit them over the crankshaft, then assemble the oil seal using an oil seal fitting jig.



### 3.3.8. Flywheel




- Install a guide bar into a bolt hole on the crankshaft, and lift the flywheel to align the dowel pin with the pin hole on the flywheel for temporary assembly operation.

- Install bolts in the remaining holes, take out the guide bar, then install a bolt in the hole where the guide bar had been inserted.



- Tighten the fixing bolts using a torque wrench in a diagonal sequence to specified torque.




Torque	20 ±3.6 kg.m
--------	--------------



#### CAUTION:

Flywheel fixing bolts can only be reused up to 3 times; reusing them more than that may cause damage.



### 3.3.9. Cylinder liner

- Stand the cylinder block so that the fly-wheel faces downward.




- Thoroughly clean the liner flange fitting surface and bore inside with compressed air to prevent the entry of foreign substances.

- After the cleaning operation, make the cylinder liner dried up and push it into the cylinder block by hand.




- Wet the liner inside diameter with engine oil.




### 3.3.10. Piston and connecting rod



- Use a piston heater to heat the piston approximately 100°C (212°F) for 5 minutes.



- Align the piston pin hole with the oiled connecting rod small end and press the piston pin (by lightly tapping with a rubber hammer) to assemble the connecting rod with the piston.





- Nothing the direction of the piston, make the longer side(machined with key groove on the bearing) of the connecting rod big end.



- On the piston head surface, the longer side connecting rod big end is in opposite direction from the valve seating surface as well as in the same direction with the narrow margin of the combustion chamber.



- Install the snap rings and check to see that it is securely assembled.



- Install the piston ring in the piston using piston ring pliers.






- Identify the mark "Y" or "TOP" on the ring end to prevent the top and bottom of the piston ring from being interchanged and make the marked portion face upward.



- Adjust the angle among individual piston ring gaps to 90° and fit a piston assembling jig onto the piston. Use care not to match the ring gaps with the pin direction.




- Install the bearing by aligning it with the connecting rod key groove and apply oil to the bearing and piston.



- Position the valve seating surface toward the tappet hole and insert the piston with hand.


Use care not to damage the cylinder liner and piston, and slightly lift and insert the piston into the cylinder so that the ring may not be damaged by the fillet of the liner.



- Install the bearing in the connecting rod cap and apply oil.



- Make sure that the manufacture serial numbers impressed on the connecting rod cap and connecting rod big end are identical, and install the connecting rod cap by aligning it with dowel pin.



- Semi-tighten the fixing bolts with hand, tighten them to 15kg.m for 1st stage and 22kg.m for 2nd stage respectively, and finally to specified torque.

Torque	1st Step	8 ±0.4 kgf·m
	2nd Step	60° ±3°




**CAUTION:**

**Connecting rod bearing bolts can only be reused up to 3 times; reusing them more than that may cause damage.**




- Move the bearing cap with hand, and release and reassemble it if no movement is detected.



### 3.3.11. Timing gear case




- Mount gasket using dowel pin on the cylinder block.
- Install the timing gear case by aligning the dowel pin with the dowel pin hole on the timing gear case.



### 3.3.12. Timing gear




- Install the oil pump idle gear onto the No.7 bearing cap.
- Install a thrust washer over the camshaft and assemble the cam gear by aligning it with camshaft key groove.



- With the oil port on the idle gear pin facing the cylinder block, install the idle gear pin.

Torque	2.2 kg.m
--------	----------




- Install the idle gear by coinciding the marks impressed on the crank gear, cam gear, trigger wheel drive gear, and idle gear.



- Install a thrust washer on the idle gear and tighten to specified torque.

Torque	6.2 kg.m
--------	----------





- Check and adjust the amount of backlash between gears using a feeler gauge.

Backlash	0.15 ~ 0.25 mm
----------	----------------


### 3.3.13. Oil pump and oil pipe



- Install a dowel pin in the No.7 bearing cap, then assemble the oil pump with specified torque.


Torque	4.4 ±1.1 kg.m
--------	---------------

- Assemble the oil suction pipe with the delivery pipe, then install the bracket on the bearing cap.



### 3.3.14. Timing gear case cover


- Install dowel pin on the timing gear case.
- Mount a gasket by aligning the fixing bolt holes with those on the gasket.
- Align the dowel pin with the cover pin hole, then install the cover with light tap.
- Tighten the fixing bolts beginning with the oil pan fitting face.



### 3.3.15. Front oil seal



- Apply lubricating oil to the outside of the oil seal and timing gear case inside diameter and fit them over the crankshaft, then assemble the oil seal using an oil seal fitting jig.




### 3.3.16. Vibration damper end pulley

- Install the vibration damper on the crankshaft pulley.
- Install the crankshaft pulley assembly on the crankshaft, then tighten the bolts and thrust washers.



Torque	13.4 ±1.3 kg.m
--------	----------------




### 3.3.17. Relief valve

- Assemble the relief valve from the joints of the timing gear case, case cover, case cover and flywheel housing.
- Apply silicon to each joint and attach gasket to the cylinder block.
- Tighten fixing bolts at both ends, intermediate bolts and remaining bolts in the described order.



Torque	2.2 kg.m
--------	----------




### 3.3.18. Oil pan

- Mount gasket and put the oil pan thereon.
- Place stiffeners and tighten bolts.
- Align the bolt holes with gasket holes to prevent damage to the gasket and tighten to specified torque.



Torque	3.1 ±0.31 kg.m
--------	----------------





### 3.3.19. Oil Cooler

- Install the oil cooler onto the oil cooler cover
- Carefully apply the gasket to prevent oil leakage
- Do not damage the gasket and install the cover onto the cylinder block.
- Connect a connection pipe between the water pump and oil cooler.




Torque	2.2 ±0.22 kg.m
--------	----------------



### 3.3.20. Oil filter



- Install the oil filter onto the cylinder block, and tighten the fixing bolts.
- With the hollow screw, assemble the oil pipe connected between the oil cooler and cylinder block.
- Install a connection pipe between the oil cooler and oil filter.
- Install the oil cooler connecting pipe.
- Install packing and assemble the cartridge using a filter wrench.



### 3.3.21. Water pump

- Mount a new O-ring on the water pump.
- Install the water pump on the timing gear case cover and then tighten in tightening sequence to specified torque.
- Connect water pipes and by-pass pipe to the water pump.


Torque	6.2 ±1.55 kg.m
--------	----------------



### 3.3.22. Starter

- Assemble the starter in position on the flywheel housing.

Torque	6.2 ±1.55 kg.m
--------	----------------





### 3.3.23. Intake and exhaust valves



- Identify the mark of "GI" and "GE" impressed on the valve head before assembling the valve with the valve head.




- With a valve stem seal fitting jig, assemble the valve stem seal with the valve guide.



- After installing valve springs and spring retainer, press the retainer with a jig, then install cotter pin.



- Tap the valve stem lightly with a rubber hammer to check that the valve is assembled correctly.




### 3.3.24. Spark plug tube



- Apply sealant (Loctite 272) to the spark plug and place the O-ring over the cylinder head fitting face on the spark plug tube, then install the spark plug tube in the cylinder head.

- After mounting the spark plug tube, make hydraulic test to check for water leaks.

Test pressure	2 kg/cm <sup>2</sup>
---------------	----------------------



### 3.3.25. Ignition coil and spark plug




- Install the gasket and ignition coil cover into the cylinder head, then tighten the fixing nuts.



- Tighten the spark plug at cylinder head with socket tool.

- Assemble the ignition coil onto ignition coil cover.

Socket tool	Hex. head 16 mm (5/8 inch)
Spark plug torque	2.5 ~ 3.0 kg.m



### 3.3.26. Cylinder head

- Install the ignition coil covers and water pipe fixing stud bolts.




- Clean the head bolt holes on the cylinder block with compressed air to remove foreign substances and thoroughly clean the gasket fitting face of the cylinder block.



- Install head gasket, with "TOP" mark facing upward, on the cylinder block by aligning the holes with dowels.




- Check the inside of combustion chamber for foreign substances, and carefully mount the cylinder head assembly in the block by aligning the dowel pin with the dowel pin hole. Be careful not to damage the head gasket. If the dowel pin is not in alignment, lift the cylinder head again and then remount it.







- Tighten the head bolts in proper sequence to the specified torque.

< Cylinder head bolts >

	Type
Head bolts	 M14 x 1.5
Torque	$6 \pm 0.6 \text{ kgf.m} \rightarrow 90^\circ \pm 9^\circ \rightarrow 90^\circ \pm 9^\circ$



- Coat the push rod with engine oil and insert it into the push rod hole.



- Adjust the valve clearance as following guide.



**CAUTION:**  
Do not reuse the cylinder head bolts when assembling the cylinder head.


3.3.27. Rocker arm assembly




- Apply lubricating oil to the rocker arm bush and shaft, and assemble the intermediate bracket with the rocker arm using fixing bolts.



Torque	M10 x 1.5	$6.2 \pm 0.62 \text{ kg.m}$
	M8 x 1.25	$2.2 \pm 0.22 \text{ kg.m}$



- Semi-install valve clearance adjusting bolts onto the rocker arm.
- Install the spring, rocker arm, bracket, rocker arm, spring, washer, and snap ring in the described sequence.
- Install the rocker arm and bracket in the same direction.




### 3.3.28. Timing Trigger wheel & bearing housing



- Mount gasket by aligning the bolt holes with pin holes on the timing drive gear housing.
- After tighten the fixing bolts in the direction of the coupling.

Trigger wheel run-out	Bellow 0.2 mm
-----------------------	---------------



### 3.3.29. Ignition timing adjustment




- Ignition timing sensor and trigger wheel location is affected the engine starting that refer to bellow the described order.

#### ● Check ignition timing angle


- 1) Turning the crankshaft, let the valves of #6 cylinder's valves overlap.
- 2) Check notch mark of the right figure corresponding to the ignition timing aligner with the pointer



( ↓ ) on the flywheel housing.



Model	GE12TIC
Ignition timing (B.T.D.C static)	13°





#### ● Adjust ignition timing angle

- 1) Loosen the trigger wheel lock bolts, and align the sensor on the trigger wheel at starting position of the undivided holes (as bellow figure) and then tighten the trigger wheel lock bolts.




Trigger wheel lock bolt torque	2.0 kg.m
Timing sensor gap	1.0 mm $\pm$ 0.1 mm





● **Adjust ignition timing sensor gap**

- 1) Move the lock nut to hexagonal side of sensor completely.
- 2) Rotate (Clockwise) the timing sensor on the coupling housing, until the end of it reach on the timing drive gear.
- 3) Then rotate (Counter clockwise) the timing sensor for 270° (gap 1.0 mm) and fix lock nut.
- 4) Tolerance limit is 27°. (gap  $\pm 0.1$  mm)




- Assemble the timing sensor bracket, protect cover and ignition timing sensor.

● **Assemble the ignition timing sensor to timing gear housing.**

Trigger wheel lock bolt torque	0.8 kg.m
--------------------------------	----------

Timing sensor gap	1.0 mm $\pm 0.5$ mm
-------------------	---------------------




### 3.3.30. Intake manifold



- Fit a gasket on the intake manifold before assembling the intake manifold and tighten the fixing bolts.

Torque	4.4 ±0.44 kg.m
--------	----------------




### 3.3.31. Exhaust manifold

- Install the exhaust manifold by aligning the gasket with the exhaust port on the cylinder head so that the face and back of the gasket can be positioned correctly.



**CAUTION:**  
Be careful to remove the exhaust manifold. It is very heavy.

Torque	M10 x 1.5	4.4 ±0.44 kg.m
	M12 x 1.5	8.0 ±0.8 kg.m




### 3.3.32. Turbocharger




- Fit a new gasket over the stud bolts of the exhaust manifold before tightening those turbocharger fixing bolts.
- Install the oil supply pipe and return pipe.

Torque	4.4 kg.m
--------	----------




### 3.3.33. Thermostat

- Install the thermostat housing on the exhaust manifold.
- Assemble the thermostat and water out pipe.



### 3.3.34. Intercooler & throttle valve

- After sub-assembling the air inlet and outlet pipe on the intercooler.
- Install the intercooler on the bracket of flywheel housing and tightening the fixing bolt on it.
- Assemble the throttle valve and air pipe on the intake manifold.



#### CAUTION:

**Check assembled after the all engine parts install and tighten fuel line.**

**Open fuel line valve and check for leaks using soapy water or commercial leak detector.**

### 3.3.35. Fuel mixer & gas pressure regulator


- Assemble the fuel mixer and air pipe from the turbo charger.
- Tighten the gas pressure regulator and nature gas pipe from the fuel mixer.



#### CAUTION:


**Check assembled after the all engine parts install and tighten fuel line.**

**Open fuel line valve and check for leaks using soapy water or commercial leak detector.**




### 3.3.36. Ignition control module : ICM

- Mount the ignition control module(ICM) bracket on the cylinder block.
- Assemble the fixing bolts with the ignition control module.



### 3.3.37. Ignition coil & high voltage cable

- Install the bracket on the intake manifold and assemble the ignition coils
- Assemble the high voltage cables by hand from each cylinder head.




### 3.3.38. Cooling water pipe

- Attach a new gasket on the cylinder head.
- Install the cooling water pipe and tightening the fixing bolt on it.



Torque	2.2 ±0.22 kg.m
--------	----------------




### 3.3.39. Alternator




- Install the alternator mounting bracket and supporter to the cylinder block, then tighten the fixing bolts.
- Install the alternator with fixing bolts to the mounting bracket.

Torque	8 ±2 kg.m
--------	-----------



### 3.3.40. V- belt

- Install the V-belt on the crank pulley, alternator pulley.
- Adjust the V-belt tension using the tension adjusting bolt.




### 3.3.41. Cylinder head cover

- Assemble the cover packing with the cover, install the cover on the head, then tighten the fixing bolts in sequence to specified torque.




Torque	3.1 ± 0.3 kg.m
--------	----------------

- Assemble the breather hose with PCV valve.




### 3.3.42. Oil level gauge

- Assemble the oil level gauge and guide tube on the oil pan.



### 3.3.43. Engine speed controller : ESC

- Install engine speed controller (ESC) and connect the harness and various sensors.



### 3.4. Starting and trial operation

#### 3.4.1. Preparations for breaking-in



- Fill of new engine oil through the oil filler cap.
- When measuring the oil level with the oil level gauge with the engine mounted, the oil level must indicate about 10mm above the max. line.
- Connect water hoses and fill up cooling water.
- Connect the fuel hoses to the fuel tank and to top(radiator or surge tank).
- Check the air bleeding of the fuel system.
- Connect the electrical systems such as starter, air heater, etc. with power source.

#### 3.4.2. Operation of a new engine (*Break-In*)

Because the sliding surfaces of a new engine are not lapped enough, the oil film can be destroyed easily by overload or overspeed and the engine life-time may be shortened.

Therefore the following things must be obeyed by all means.

##### ***Up to the first 50 hours***

- Engine should be run at fast idling until the temperature of the engine becomes normal operating condition.
- Overload or continuous high speed operation should be avoided.
- High speed operation with no load should be prevented.
- Abrupt start and stop of the engine should be avoided.
- Engine speed must be under 70% of its maximum speed.
- Maintenance and inspection must be accomplished thoroughly.

#### 3.4.3. Check points for break-in

During the *break-in* (the initial running of the engine) period, be particularly observant as follows:

Check engine oil level frequently. Maintain oil level in the safe range, between the "min." and "max." marks on dipstick.



##### **Note:**

**If you have a problem getting a good oil level reading on dipstick, rotate dipstick 180° and re-insert for check.**

Watch the oil pressure warning lamp. If the lamp blinks, it may be the oil pick-up screen is not covered with oil. Check oil dipstick. Add oil to the oil pan, if required. Do not overfill. If level is correct and the status still exists, see your DEALER for possible switch or oil pump and line malfunction.



##### **Note:**

**Oil pressure will rise as RPM increases, and fall as RPM decreases. In addition, cold oil will generally show higher oil pressure for any specific RPM than hot oil. Both of these conditions reflect normal engine operation.**

Watch the engine water temperature gauge and be sure there is proper water circulation. The water temperature gauge needle will fluctuate if water level in expansion tank is too low. At the end of the break-in period, remove break-in oil and replace the oil filter. Fill oil pan with recommended engine oil. Refer to following table.

Engine model	Engine oil capacity				Recommend oil	
	in Oil pan		Total (lit)	Remark	API No.	Sulfated ash content
	Max. (lit)	Min. (lit)				
GE12TIC	30	24	33	Standard	SAE 15W40 CD/SF or later	Bellows 0.5%
	50	33	53	Optional		

## 3.5. Speed controller setting

### 3.5.1. Installation checks



Do the checks in the order indicated. Terminal numbers in this chapter refer to the speed controller.

- 1) Check that all electrical connections are correctly made and terminal screws tightened, the magnetic pickup is properly installed and the jam nut tightened, and the fuel valve and drain line are securely fastened and correctly installed.
- 2) Do not start the engine now. Turn on governor power. Check the battery voltage at terminals 1(+) and 2(-). It must be from 18 to 32Vdc.
- 3) **If a signal generator is available** : Attach the output to terminals 5 and 6, leaving the magnet pick-up connections off. Set the signal-generator output between 2 and 10 Vrms. If a signal generator is not available, proceed to step 8.
- 4) Set the signal-generator frequency to about half of idle speed. Close the **IDLE/RATED** switch. Turn the signal generator and governor power on. The voltage across terminals 3 and 4 should measure about 5Vdc (**START FUEL LIMIT** must be fully clockwise).
- 5) Set the signal generator for magnet pick-up frequency at rated speed. Close the **IDLE/RATED** switch. Set the external speed trim pot (if used) at mid position. Observe the output from terminals 3 and 4.
  - a) If the output is at max-fuel position (about 5Vdc), slowly turn the rated-speed potentiometer counterclockwise until the signal just begins to move to minimum.
  - b) If the output is at minimum, slowly turn the rated-speed potentiometer clockwise until the signal just begins to move to maximum.
  - c) Continue to adjust the rated-speed pot very slowly, trying to stop the signal between minimum and maximum. Stop adjusting when the signal moves slowly. It will not be possible to stop the motion. The rated-speed reference is now set very close to desired speed.
- 6) Open the **IDLE/RATED** switch. Set the signal generator for magnet pick-up frequency at idle speed. (Preset the idle speed only after presetting rated speed.)
  - a) If the signal is at maximum-fuel position, slowly turn the idle-speed potentiometer counterclockwise until the signal begins to move to minimum.
  - b) If the signal is at minimum, slowly turn the idle-speed potentiometer clockwise until the signal just begins to move to maximum.

- 7) Continue to adjust the idle-speed pot very slowly, trying to stop the signal between minimum and maximum. Stop adjusting when the signal moves slowly. It will not be possible to stop the signal. The idle-speed reference is now set very close to desired idle speed.
- 8) **If a signal generator is not available:** turn the rated speed pot fully counterclockwise. Turn the idle-speed pot fully clockwise. Remove the magnet pick-up wires from the speed control and measure resistance across the magnet pick-up wires. If the resistance is correct replace the connection.

### 3.5.2. Initial pre-start settings

In case the newly installed the speed controller does not control engine speed, be prepared to belows sequence.

#### 1. Rated Speed

If **RATED SPEED** was not set with a signal generator, set the **RATED SPEED** potentiometer to minimum (fully counterclockwise). Set the external speed trim, if used, to mid-position.

#### 2. Stability

Set the **RATED** and **IDLE STABILITY** potentiometers to mid position.

#### 3. Gain

Set the **RATED** and **IDLE GAIN** potentiometers to mid position.

#### 4. Idle Speed

If **IDLE SPEED** was not set with a signal generator, set the **IDLE SPEED** potentiometer at maximum (fully clockwise).

#### 5. Start Fuel Limit

Set the **START FUEL LIMIT** pot at mid point (maximum is fully clockwise).

6. Close the circuit between terminals 9 and 10 (Close for rated).

### 3.5.3. Start-up and stable adjustments

Prepare to start the engine. Read this entire chapter before attempting to start the engine. Interrelated problems can occur, and an understanding of all possibilities is needed before using a control for the first time.



#### **CAUTION:**

**To protect against possible injury, loss of life, and/or property damage when starting the engine, turbine, or other type of prime mover, be prepared to make an emergency shutdown to protect against runaway or overspeed should the fuel control(s), the driving mechanism(s), or the control device(s) fail.**

1) Adjust for stable operation

Read the following paragraphs before attempting initial engine start up. Dynamics must be quickly adjusted after initial start up.

2) Immediately after the initial start up, it will be necessary to adjust the governor for stable operation. Idle and Rated dynamics are completely separate. In most cases the idle speed has been preset at maximum (fully clockwise) and Rated Speed is selected. In many cases the selection of rated speed will not indicate a desire for rated dynamics, which will be used when the engine is loaded. Idle dynamics may be selected and adjusted while rated speed is selected.

3) If the engine is hunting at a rapid rate, slowly decrease the **GAIN** (turn the potentiometer counterclockwise) until performance is stable.

4) If the engine is hunting at a slow rate, increase the **STABILITY** (turn the potentiometer clockwise) until the engine stabilizes. If increasing the **STABILITY** potentiometer does not stabilize the engine, it also may be necessary to slowly decrease the **GAIN** (turn the potentiometer counterclockwise).

a) Start cranking the engine. If the signal from terminals 3 and 4 does not show a positive voltage (2 to 6 Vdc) check the magnetic pick-up sensor.

b) Minimum voltage required from the magnetic pick-up sensor to operate the electronic control is 1.0 Vrms, measured at cranking speed or the lowest controlling speed. Measure the voltage while cranking with the speed sensor connected to the control. Be sure to prevent the engine from starting.

5) If the engine stops, it indicates a magnetic pick-up problem. The magnetic pick-up must produce a minimum of 1 Vac rms to activate the control. Failure to produce the minimum signal can be caused by improper magnetic pick-up installation, selection of an incorrect gear, improper wiring between the magnetic pick-up and the control, or a defective magnetic pick-up.

6) With the engine running and stable, slowly increase the rated-speed setting with the **RATED SPEED** pot until the desired rated speed is reached.

7) Dynamic adjustment


The object of the **GAIN** and **STABILITY** potentiometer adjustments is to obtain the optimum, or desired, stable engine-speed response.

8) Increasing the setting of the **GAIN** potentiometer provides faster transient response (decreases the amount of speed change from a sudden change in load).


To achieve the best response, slowly increase the **GAIN** (turn the potentiometer clockwise) until the engine becomes slightly unstable, then slowly turn the **GAIN** back counterclockwise as necessary to stabilize engine speed.

9) Step load the engine to make sure the engine returns to the proper speed with little overshoot or undershoot of the speed setting. (To reduce overshoot, increase the **STABILITY** setting by turning the potentiometer clockwise).


- 10) Increasing the **STABILITY** clockwise will require decreasing the GAIN (turning the GAIN potentiometer counterclockwise) to maintain stable operation.
- 11) If the engine is slow in returning to the proper speed, decrease the **STABILITY** by turning the potentiometer counterclockwise.
- 12) **Low idle speed adjustment:** The engine should be at rated speed with the **IDLE SPEED** potentiometer set at maximum (fully clockwise). Open the external **CLOSE FOR RATED** contact.
- 13) Decrease the **IDLE SPEED** (turn the potentiometer counterclockwise) until the desired idle speed is reached. It may be necessary to adjust the idle dynamics to maintain stability as speed is lowered.
- 14) Dynamic Adjustment
  - a) Gain is too high and stability too low. There are secondary overshoots on transients and large overshoots on starts (under damped)




- b) Optimum performance on load transients with slight overshoot on starts (optimum damping)



c) Optimum performance on start with slight time extension of load transients (optimum damping)




d) Stability too high, long time to settle to rated speed (over damped)



- 15) If idle dynamics were selected on initial start-up, it will now be necessary to set rated dynamics. Load the engine, then select rated dynamics.
- 16) Engine response will change as the engine warms up. It may be necessary to tune dynamics after warm-up. It may be necessary to compromise optimum control dynamics with a cold engine in order to have optimum dynamics when the engine is at operating temperature.
- 17) The **START FUEL LIMIT** was set at a point that allowed the cold engine to start during initial start up procedures. If **START FUEL LIMIT** is to be used, it should now be adjusted after engine stability and response rates are correctly adjusted.
  - a) Adjusting the **START FUEL LIMIT** counterclockwise will prevent the fuel valve from delivering a maximum amount of fuel to the injectors until the selected speed (Idle or Rated) is reached. Adjust for desired engine performance during start up. The Start Fuel Limit must be set high enough to allow the engine to reach the selected speed.
  - b) The **START FUEL LIMIT** should be adjusted from counterclockwise to obtain the desired characteristics while starting the engine. There may be differences in startup characteristics of cold and hot engines.

### 3.6. Electrical system


#### 3.6.1. Electrical component of engine



EF5OM033


- |                                  |                           |
|----------------------------------|---------------------------|
| 1. Oil pressure unit             | 6. Ignition timing sensor |
| 2. Throttle valve                | 7. Alternator             |
| 3. Ignition coil                 | 8. Starter                |
| 4. Gas pressure regulator        | 9. Nature gas air mixer   |
| 5. Ignition control module (ICM) |                           |

### 3.6.2. Engine control system



EF2OM038

### 3.6.3. Engine control harness




EF2OM039


### 3.7. Speed controller

#### 3.7.1. Speed controller description

- The speed controller is designed to provide basic isochronous speed control for gas engines.
- Engines with mechanical loads and generator loads are handled equally well.




### 3.7.2. Speed controller circuit



- **1** Shield wires to be twisted pairs with shield grounded at one end only.
- **2** No. 18AWG or 20AWG standard wire. Must be as short as possible. 50ft. maximum wire length for 20AWG wire. 80ft. maximum wire length for 18AWG wire.
- **3** Use 24 volt system.
- **4** Open for minimum fuel.
- **5** For positive ground systems, switch and fuse to be located in series with battery (-) and terminal 2. Positive terminal becomes chassis ground. Leads from battery to terminals 1 & 2 must be direct and not pass through distribution points.
- **6** Approximate speed change with trim potentiometer
  - ◆  $\pm 2.5\%$  using a  $1K\ \Omega$  potentiometer
  - ◆  $\pm 5\%$  using a  $2K\ \Omega$  potentiometer
- **7** About one second ramp time per  $50\ \mu F$ . Capacitor specifications :  $200\ \mu F$  maximum,  $15WVdc$  minimum.  $15WVdc$  maximum. Less than  $30\ \mu A$  DC leakage current over temperature range.
- **8** Idle range about 25% to 100% rated using 50K potentiometer.
- **9** Use a 1 amp fuse(3 AWG)


### 3.8. Ignition controller

#### 3.8.1. Ignition controller circuit



EF20M041


### 3.8.2. DC power hookup of ignition system




### 3.8.3. Engine firing order

Engine model	GE12TIC
Firing order	1 - 5 - 3 - 6 - 2 - 4

### 3.8.4. Engine cylinder no.




### 3.8.5. Primary wiring



Terminal position	Terminal symbol	Wiring	Connector position
Spark coil	1+	1.25R	Connector A
	1-	1.25B	Connector J
	2+	1.25R	Connector E
	2-	1.25B	Spark coil 1-
	3+	1.25R	Connector C
	3-	1.25B	Spark coil 2-
	4+	1.25R	Connector F
	4-	1.25B	Spark coil 3-
	5+	1.25R	Connector B
	5-	1.25B	Spark coil 4-
	6+	1.25R	Connector D
	6-	1.25B	Spark coil 5-
	Ground	1.25B	Spark coil 6-

### 3.8.6. Tacho sensor wiring



Terminal position	Terminal symbol	Wiring	Connector position
Tacho sensor	Signal(SIG)	0.85W	Connector A
	Ground(GND)	0.85W	Connector B

## 3.9. Ignition control module

### 3.9.1. Installation instruction



**CAUTION:**

**Deviation from these installation instructions may lead to improper engine operation which could cause personal injury to operations or other nearby personnel.**

### 3.9.2. Description

- The CD1 ignition system consists of these basic components.
  - 1) CD1 unit
  - 2) Magnetic pick-up sensor
  - 3) Harness
  - 4) Individual coils
  
- The system requires a battery or a suitable power supply with a nominal 24 VDC. The CD1 unit steps up the DC supply voltage to charge an energy storage capacitor and contains microcircuit logic and SCR(Silicon controlled rectifier switching) devices to release the stored energy to the ignition coils in programmed, timed sequence according to the application. Holes drilled in the trigger wheel signal the position of the trigger coupling to the logic circuitry in the CD1 unit.

### 3.9.3. CD1 unit



- Select a location for the CD1 unit that will be at least 600 mm away from the ignition coils and spark plug leads. In addition, the mounting location must be relatively cool. The outside case temperature of the CD1 unit should not exceed 90°C (195°F) in operation.



**NOTE:**

**Plastic-case CD1 units have a maximum case temperature of 65°C (150°F).**

#### 3.9.4. Pick-up sensor

- Locate a suitable mounting position for the pick-up sensor so that it may sense either the outside diameter of the trigger wheel.



**IMPORTANT:**

**Rotate the trigger wheel an entire revolution to be sure that there are holes in the path that will pass under the pick-up sensor.**

- Set the engine with no. 1 cylinder in the most advanced timing position. Mark the point on the trigger wheel that will be directly opposite the pick-up sensor.



**NOTE:**

**When assembled trigger wheel is extremely important as this establishes the basic timing accuracy of the system. In addition, make sure each hole is drilled so that its center passes directly in line with the center of the pick-up sensor.**

- Secure the pick-up sensor to a rigid bracket or surface to maintain an air gap(1.0 mm  $\pm$ 0.1 mm) not exceeding. The center of the pick-up face must line up with the center of the drilled holes as the engine is rotated.
- Plug the 2-pin pick-up sensor connector fully into its mating receptacle connected to the CD1 unit.



**NOTE:**


**Keep the pick-up sensor wires at least 50 mm away from the coil primary wires and at least 200 mm away from the spark plug leads.**

#### 3.9.5. Trigger wheel

- The angular spacing is extremely important as this establishes the basic timing accuracy of the system.
- Set the engine with no. 1 cylinder in the most advanced timing position. Noting the direction of rotation, set the drilled disc opposite the pick-up in the position shown in circuit diagram.
- Plug the 2-pin pick-up sensor connector fully into its mating receptacle connected to the CD1 unit.

### 3.9.6. Ignition coils

- Mount the ignition coils as close to the spark plugs as possible keeping the high-tension lead length to a minimum but also keeping temperatures below 95°C (200°F) during operation.



### 3.9.7. Primary wiring

- The CD1 system requires a battery or other DC power source providing 12~28VDC for running and a minimum of 8 volts for engine starting. Refer to details the connection to the DC power source.
- Plug the multi-pin harness connector fully into its mating receptacle connected to the CD1 unit.



#### NOTE:

Keep the primary wiring at least 50 mm away from the spark plug leads.

### 3.9.8. Shutdown wiring

The CD1 system can be shut-off in two ways.

(Refer to 3.7.1. Ignition controller circuit - CD1 system)

- **Method 1:** (use to DC power source)

Interrupt the DC power to the unit.

- Use a switch or relay with contacts rated 24VDC, 10 amps refer to drawing.
- Do not run the input power line through a series of normally closed switches.

● **Method 2:** (use to "G" ground)

- Ground the appropriate harness lead. This option may be used if the shutdown panel was powered from an ignition system.
- When the shutdown lead is grounded, the CD1 unit will draw about 0.1 amp from the power source.



**NOTE:**

**If desired, the shutdown lead may be used to power display instruments in the panel.**

### 3.9.9. Operation

- The CD1 unit steps up the DC supply voltage to charge an energy storage capacitor. SCR switching devices release this stored energy in response to signals from the unit's logic circuitry which processes signals from the magnetic pick-up. The pick-up senses one hole for every firing of the engine. Each firing occurs a programmed number of degrees after the hole is sensed. This delay in degrees is adjustable.
- The CD1 unit has a timing switch located under a white plastic cap at one end of the box.
  - 6 cylinder engine : 1.9 degrees per switch interval = 13 degrees total
- Switch position 7 gives the most advanced timing. The timing retards as indicated above for each switch position as the switch is moved to position 1-5-3-6-2-4. Switch position 0 is full retard.



**CAUTION:**

**Do not switch from position 7 to 0, or 0 to 7 while the engine is running. The large timing change may cause the engine to shutdown or be damaged.**



**NOTE:**

**Using a timing light, set the timing to the desired position with the engine running at normal operating speed. Replace the white cap over the timing switches once the proper timing setting is set.**

- Two LED indicators on either side of the timing switch give an indication of proper operation of the magnetic pick-up (left LED) and the output circuits of the CD1 unit (right LED). See troubleshooting procedures.

### 3.9.10. Troubleshooting chart

#### ● Normal operation

Check the two LED indicators next to the timing switch.

- After power is turned on to the CD1 unit, the output indicator will turn on.
- When the engine is cranked, both indicators will blink at the same rate.
- At normal running speeds, both indicators glow continuously.
- If engine is stopped with power off, the output indicator will turn off for a few seconds and then stay on continuously.

#### ● Trouble shooting

- Check the two LED indicators next to the timing switch.
- If the engine will not start or run correctly, crank engine with fuel turned off and check per the chart below.

Indication and checks	Remedy
1. Both indicators off. ● Check 12 ~ 24 VDC power to CD1 unit. ● If above check is OK.	● Must be in range of 12 ~ 29 VDC. ● Replace CD1 unit.
2. Pick-up indicator off / Output indicator On. 1) Check gap between pick-up and sensed surface. - must be greater than 1.0 mm $\pm$ 0.1 mm. 2) Check connections between CD1 unit and the pick-up sensor. 3) Unplug connection to pick-up and measure resistance between the two pick-up leads. 4) If above checks are OK.	● Correct gap.  ● Correct connections.  ● Replace pick-up.  ● Replace CD1 unit.
3. Pick-up indicator OK / Output indicator off or blinks at slower rate. 1) Check connections between CD1 unit and ignition coil module or coils. 2) If above check is OK.	● Correct connections.  ● Replace CD1 unit.
4. Both indicators blink at the same rate. 1) Indicates proper operation of CD1 unit and magnetic pick-up sensor.	● Check or replace ignition coils. ● Check other items such as fuel supply.

## 4. Commissioning and Operation

### 4.1. Operation preparation

At the time of initial commissioning of a new or overhauled engine make sure to have observed the "Technical information for the installation HD Hyundai Infracore generator engines".

#### ● Oil filler neck on cylinder head cover

- Before daily starting of the engine, check the fuel, coolant and oil level, replenish if necessary.
- The notches in the oil level gauge indicate the highest and lowest permissible oil levels.



#### **IMPORTANT:**

**Do not fill above the top of the mark. Oil levels anywhere within the crosshatch are considered in the acceptable operating range. Over lifting will result in damage to the engine.**

#### ● Cleanliness

Ensure utmost cleanliness when handling fuels, lubricants and coolants

### 4.2. Breaking-in

#### 4.2.1. Preparations for breaking-in

- Fill of new engine oil through the oil filler cap.



- When measuring the oil level with the oil level gauge with the engine mounted, the oil level must indicate about 10mm above the max. line.
- Connect water hoses and fill up cooling water.
- Connect the electrical systems such as starter, alternator, etc. with power source.

#### 4.2.2. Operation of a new engine (*Break-In*)

Because the sliding surfaces of a new engine are not lapped enough, the oil film can be destroyed easily by overload or overspeed and the engine life-time may be shortened. Therefore the following things must be obeyed by all means.

##### ***Up to the first 50 hours***

- Engine should be run at fast idling until the temperature of the engine becomes normal operating condition.
- Overload or continuous high speed operation should be avoided.
- High speed operation with no load should be prevented.
- Abrupt start and stop of the engine should be avoided.
- Engine speed must be under 70% of its maximum speed.
- Maintenance and inspection must be accomplished thoroughly.

### 4.2.3. Check points for break-in

During the break-in (the initial running of the engine) period, be particularly observant as follows:

- a) Check engine oil level frequently. Maintain oil level in the safe range, between the "min." and "max." marks on dipstick.



**Note :**

**If you have a problem getting a good oil level reading on dipstick, rotate the level gauge 180° and re-insert for check.**

- b) Watch the oil pressure warning lamp. If the lamp blinks, it may be the oil pick-up screen is not covered with oil. Check oil level gauge. Add oil to the oil pan, if required. Do not overfill. If level is correct and the status still exists, see your DEALER for possible switch or oil pump and line malfunction.



**Note :**

**Oil pressure will rise as RPM increases, and fall as RPM decreases. In addition, cold oil will generally show higher oil pressure for any specific RPM than hot oil. Both of these conditions reflect normal engine operation.**

- c) Watch the engine water temperature gauge and be sure there is proper water circulation. The water temperature gauge needle will fluctuate if water level in expansion tank is too low.

At the end of the break-in period, remove break-in oil and replace the oil filter. Fill oil pan with recommended engine oil. Refer to following table.

- The following oils are also recommended

SAE No.	API No.	Sulfated ash content
15W40	CD/SF or later	Bellow 0.5%

- Engine oil capacity

Engine oil capacity				
Engine model	in Oil pan		Total (lit)	Remark
	Max. (lit)	Min. (lit)		
GE12TIC	30	24	33	Standard
	50	33	53	Optional

#### **4.2.4. Operating after break-in**

When starting a cold engine, always allow the engine to warm up gradually. Never run the engine at full throttle until the engine is thoroughly warmed up. Be sure to check the oil level frequently during the first 50 hours of operation, since the oil consumption will be high until the piston rings are properly seated.

### **4.3. Inspections after starting**

During operation the oil pressure in the engine lubrication system must be monitored. If the monitoring devices register a drop in the lube oil pressure, switch off the engine immediately. And the charge warning lamp of the alternator should go out when the engine is running.

- Do not disconnect the battery or pole terminals or the cables.
- If, during operation, the battery charge lamp suddenly lights up, stop the engine immediately and remedy the fault in the electrical system.
- Engine should be stopped if the color, the noise or the odor of exhaust gas is not normal.
- Confirm the following things through warning lamps and gauge panel.

#### **4.3.1. Pressure of lubricating oil**

The normal pressure comes up to 1 kg/cm<sup>2</sup> (1.0 bar) at idling and 3 ~ 5 kg/cm<sup>2</sup> (3.0 ~ 4.9 bar) at maximum speed. If the pressure fluctuates at idling or does not reach up to the expected level at high speed, shut down the engine immediately and check the oil level and the oil line leakage.

#### **4.3.2. Temperature of cooling water**

The cooling water temperature should be 79 ~ 95°C in normal operating conditions. Abnormally high cooling water temperature could cause the overheating of engine and the sticking of cylinder components. And excessively low cooling water temperature increases the fuel consumption, accelerates the wears of cylinder liners and shortens the engine life-time.

## 4.4. Operation in winter time

Pay special attention to the freezing of cooling water and the viscosity of lubricating oil.

### 4.4.1. Prevention against the freeze of cooling water

When not using anti-freeze, completely discharge the whole cooling water after engine running. The freeze of cooling water causes the fatal damages of the engine. Because the anti-freeze is used to prevent cooling water from freeze, consult "The amount of anti-freeze".

### 4.4.2. Prevention against excessive cooling

Drop of thermal efficiency caused by excessive cooling increases fuel consumption, therefore prevent the engine from excessive cooling. If the temperature of coolant does not reach to normal condition (79 ~ 95°C) after continuous operation, examine the thermostat or the other cooling lines.

### 4.4.3. Lubricating oil

As cold weather leads to the rise of oil viscosity, engine speed becomes unstable after starting. Therefore the lubricating oil for winter should be used to prevent this instability. Refer to lubricating system section.

## 4.5. Tuning the engine

The purpose of an engine tune-up is to restore power and performance that's been lost through wear, corrosion or deterioration of one or more parts or components. In the normal operation of an engine, these changes can take place gradually at a number of points, so that it's seldom advisable to attempt an improvement in performance by correction of one or two items only. Time will be saved and more lasting results will be obtained by following a definite and thorough procedure of analysis and correction of all items affecting power and performance.

Economical, trouble-free operation can better be ensured if a complete tune-up is performed once every years, preferably in the spring. Components that affect power and performance to be checked are:

- Components affecting fuel system ;  
Ignition coil, spark plug, metering valve etc.
- Components affecting intake & exhaust ;  
Air cleaner, inter-cooler, turbo charger, silencer, etc.
- Components affecting lubrication & cooling ;  
Air & oil filter, anti- freeze, etc.

## 4.6. Maintenance and care

### 4.6.1. Periodical inspection and maintenance

In order to insure maximum, trouble-free engine performance at all times, regular inspection, adjustment and maintenance are vital.

- Daily inspections in below figure should be checked every day.
- The maintenance should be executed thoroughly at regular intervals.  
(refer to appendix “General engine inspection cycle”)

### 4.6.2. Exchanging of lubrication oil


Engine oil and the oil filter are important factors affecting engine life. They affect ease of starting, fuel economy, combustion chamber deposits and engine wear.

At the end of the break-in period 1,000 km (50 hours), change the oil sump oil and replace the oil filter cartridge.

### 4.6.3. Oil level gauge

Check the oil level in the engine sump daily with an oil level gauge.

- The notches in oil level gauge must indicate the oil level between the max. and the min. permissible.
- The oil level should be checked with the engine horizontal and only after it has been shut down for about 5 minutes.
- Examining the viscosity and the contamination of the oil smeared at the oil level gauge replace the engine oil if necessary.





#### **CAUTION:**

**Do not add so much engine oil that the oil level rises above the max. marking on the oil level gauge. Over lifting will result in damage to the engine.**

#### 4.6.4. Oil exchange procedure

While the oil is still hot, exchange oil as follows:

- Take out the oil level gauge.
- Turn the valve opening and then move the oil drain pump lever as figure by hand, and let engine oil discharge into the prepared vessel
- Refill with new engine oil at the oil filler neck on the head cover and the lubricating oil in accordance with the oil capacity of the engine through oil filler. Be careful about the mixing of dust or contaminator during the supplement of oil. Then confirm that oil level gauge indicates the vicinity of its maximum level.
- For a few minutes, operate the engine at idling in order to circulate oil through lubrication system.
- Thereafter shut down the engine. After waiting for about 10 minutes measure the quantity of oil and refill the additional oil if necessary




#### 4.6.5. Replacement of oil filter cartridge

- At the same times of oil exchanges, replace the oil filter cartridge.
- Drain engine oil by hand pump.



**IMPORTANT:**  
**Don't forget closing the drain pump after having drained engine oil.**

- Loosen the oil filter by turning it counterclockwise with a filter wrench.
- With a rag wipe clean the fitting face of the filter body and the oil filter body so that new oil filter cartridge can be seated properly.



- Lightly oil the O-ring and turn the oil filter until sealing face is fitted against the O-ring. Turn 1-1/4 turns further with the filter wrench.



**NOTE:**

**It is strongly advisable to use HD Hyundai Infracore genuine oil filter cartridge for replacement.**

## 4.7. Cooling system

The coolant must be changed at intervals of 40,000km operation or six months whichever comes first. If the coolant is being fouled greatly, it will lead an engine overheat or coolant blow off from the expansion tank.


### 4.7.1. Coolant draining

- Remove the drain plug from the cylinder block and drain out the cooling water into a container.



**CAUTION :**

**When removing the drain plug while the engine is still hot, so that turn it slowly to release the internal steam pressure. This will prevent a person from scalding with hot steam spouted out.**



#### 4.7.2. Cleaning of the cooling inside system circuit

When the cooling system circuits are fouled with water scales or sludge particles, the cooling efficiency will be lowered. When the cooling system circuits are clogged, the water pump mechanical seal is damaged.

The poor condition of the cooling system is normally due to use of unsuitable or no anti-freezing agents and corrosion inhibitor or defect.

If twice in a short time (within 6 months) the water pump of an engine develops leaks or the coolant is heavily contaminated (dull, brown, mechanically contaminated, gray or black signs of a leakage on the water pump casing) clean the cooling system prior to removing that water pump as follows.

- a) Drain coolant.
- b) Remove thermostats, so that the whole cooling system is immediately flown through when cleaned.
- c) Fill the cooling system with a mixture of potable water and 1.5% by volume of cleaner. (Henkel P3T5175)
- d) Warm up engine under load. After a temperature of 60°C is reached, run engine for a further 15 minutes.
- e) Drain cleaning fluid.
- f) Repeat steps c) and d).
- g) Fill cooling system with hot water.
- h) Run engine at idle for 30 minutes. At the same time continuously replenish the water leaking from the bore in drain plug by adding fresh water.



**CAUTION:**

**Periodically clean the circuit interior with a cleaner.**

## 4.8. Adjustment of valve clearance

### 4.8.1. General information

The valve clearances are to be adjusted at the times of the following situations.


- After initial 1,000km (50hours) operation.
- When the engine is overhauled and the cylinder heads are disassembled.
- When severe noise comes from valve train.
- When the engine is not normally operated, even though there is no trouble in the fuel system. The valve clearance of the cold engine are as follows.

### 4.8.2. Adjusting order of the valve clearance

- 1) After letting the #1 cylinder's piston come at the compression top dead center by turning the crankshaft, adjust the valve clearances.
- 2) Loosen the lock nuts of rocker arm adjusting screws and push the feeler gauge of specified value between a rocker arm and a valve stem and adjust the clearance with adjusting screw respectively and then tighten with the lock nut.
- 3) As for the valve clearance, adjust it when in cold, as follow.

Specified Value		Measurement Tolerance	
Intake Valve	Exhaust Valve	Intake Valve	Exhaust Valve
0.4 mm	0.4 mm	±0.05 mm	

- Adjusting Sequence of Valve Clearance (1 Type)
  - By cranking the engine, let #6 cylinder's valves overlap.
  - In time, adjust the valve clearance corresponding to “ ⇐⇒ ” of lower lists.  
Rotating the crankshaft by one revolution, let #1 cylinder's valves overlap.
  - Adjust the valve clearance corresponding to “ ⇨ ” of lower lists.
  - After reinsuring the valve clearances, retighten if necessary.
- No. 1 Cylinder is located at the side where flywheel was installed.



EF20M015


● **Adjusting Sequence of Valve Clearance (2 Type)**

1 Type is the conventional and simple method, but if you have some problem to adjust your engine, please try 2 type sequence. This is a precision method, but it takes more times.

Valve overlapping on cylinder (Intake & Exhaust valve)	1	5	3	6	2	4
Adjusting valves on cylinder (Intake & Exhaust valve)	6	2	4	1	5	3

**4.8.3. Method of adjusting the valve clearance**

- 1) Loosen the lock-nuts ① using a ring spanner.
- 2) Insert a thickness gauge of 0.3mm between valve stem ② and rocker arm ③.
- 3) Turn the adjusting bolts ④ using a screw driver until the gauge can be pulled out with some restriction.
- 4) After the adjustment fix the adjusting bolt not to rotate and tighten the lock-nut at the same time.
- 5) Measure the clearance one more time and if necessary adjust again.




**4.8.4. Ignition timing adjustment**



- Ignition timing sensor and trigger wheel location is affected the engine starting that refer to bellow the described order.

● **Check ignition timing angle**


- 1) Turning the crankshaft, let the valves of #6 cylinder's valves overlap.





2) Check notch mark of the right figure corresponding to the ignition timing aligner with the pointer ( ↓ ) on the flywheel housing.

Model	GE12TIC
Ignition timing (B.T.D.C static)	13°



### ● Adjust ignition timing angle





1) Loosen the trigger wheel lock bolts, and align the sensor on the trigger wheel at starting position of the undivided holes (as bellow figure) and then tighten the trigger wheel lock bolts.




Trigger wheel lock bolt torque	4.4 kg.m
--------------------------------	----------

Timing sensor gap	1.0 mm ±0.1 mm
-------------------	----------------



● **Adjust ignition timing sensor gap**

- 1) Move the lock nut to hexagonal side of sensor completely.
- 2) Rotate (Clockwise) the timing sensor on the coupling housing, until the end of it reach on the timing drive gear.
- 3) Then rotate (Counter clockwise) the timing sensor for 270° (gap 1.0 mm) and fix lock nut.
- 4) Tolerance limit is 27°. (gap ±0.1 mm)






- Assemble the timing sensor bracket, protect cover and ignition timing sensor.

**4.9. Tightening the cylinder head bolts**

- The cylinder head bolts are to be tightened in the sequence shown in the illustrations, First tighten the bolts slightly, then slightly more again and finally tighten with a torque wrench.

**<Cylinder head bolts>**

Bolt	Type
<b>Specification</b>	 M14 x 1.5 x 150
<b>Torque</b>	1st : 6 ±0.6 kg.m 2nd : 90° ±9° 3rd : 90° ±9° 4th : 90° ±9° (Angle torque)



- The tightening by excessive torque may cause the damages of the cylinder head gaskets, the flanges of cylinder liners and the cylinder head bolts, therefore obey the regular torque.



**CAUTION:**



**Do not reuse the cylinder head bolts when assembling the cylinder head.**

#### 4.10. Cylinder compression pressure

- Stop the engine after warming it up, then remove the spark plugs.
- Install a special tool (gauge adapter) in spark plug hole and connect the compression pressure gauge to the adapter.
- Cut off fuel circulation, rotate the starter, then measure compression pressure of each cylinders.

Standard value	16 kg/cm <sup>2</sup> over
Limit value	13 kg/cm <sup>2</sup> or less
Difference between each cylinder	±10% or less

- Testing conditions:  
At water temperature of 20°C and speed of 200 rpm



## 4.11. Belts

The tension of the belts should be checked after every 2,000 hours of operation.

### 1) Change the belts if necessary

If in the case of a multiple belt drive, wear or differing tensions are found, always replace the complete set of belts.


### 2) Checking condition

Check belts for cracks, oil, overheating and wear.

### 3) Testing by hand

By the finger-pressure the belt is pressed by 10 ~ 15mm between the pulleys in normal condition. (Pressed mid-way between the belt pulleys)


A more precise check of the V-belt tension is possible only by using a V-belt tension tester.



### 4) Measuring tension


(1) Lower indicator arm ① into the scale.

- Apply tester to belt at a point midway between two pulleys so that edge of contact surface ② is flush with the V- belt.
- Slowly depress pad ③ until the spring can be heard to disengage. This will cause the indicator to move upwards.
- If pressure is maintained after the spring has disengaged a false reading will be obtained.



(2) Reading of tension

- Read of the tensioning force of the belt at the point where the top surface of the indicator arm ① intersects with the scale.
- Before taking readings make ensure that the indicator arm remains in its position.




● **V-belt tension**

Type	Drive belt width	Tensioning forces on the tester		
		new installation		When servicing after long running time
		Installation	After 10 min. running time	
<b>M</b>	9.5 mm	50 kg	45 kg	40 kg
<b>A</b>	11.8 mm	55 kg	50 kg	45 kg
<b>B</b>	15.5 mm	75 kg	70 kg	60 kg
<b>C</b>	20.2 mm	75 kg	70 kg	60 kg

**5) Tensioning and changing belts**

- Loosen fixing bolts and nuts.
- Adjust the alternator until belts have correct tensions.
- Retighten fixing bolts and nuts.

To change the belts loosen fixing bolts and nuts. Then push the alternator toward water pump pulley by hand.




## 5. Maintenance of Major Components

### 5.1. Cooling system

#### 5.1.1. General information

- This engine is water-cooling type. Heat from the combustion chamber and engine oil heat are cooled down by coolant, resulting in the normal operation of the engine.
- Looking into the cooling system, the water pumped up by the water pump circulates around the oil cooler through the water pipe to absorb the oil heat, and then flows through the water jacket of the cylinder block and water passage of the cylinder head to absorb the heat of the combustion chamber.



#### 5.1.2. Specification

Item		Specification
Water pump	Type	Centrifugal type
	Pump speed	2,100 rpm
	Delivery capacity	about 350 liter/min
	Operation pressure	0.8 bar
	Allowable back pressure	bellow 0.5 bar
Thermostat	Operating temperature	79 ~ 94°C

### 5.1.3. Diagnostics and troubleshooting


Complaints	Possible causes	Corrections
1. Engine overheating	<ul style="list-style-type: none"> <li>● Lack of coolan</li> <li>● Belt loosened or broken</li> <li>● Belt fouled with oil</li> <li>● Water pump defective</li> <li>● Restrictions in water pas-sages due to deposit of scales</li> <li>● Ignition timing incorrect</li> <li>● Gases leaking into water jacket due to broken cylinder head gasket</li> </ul>	<ul style="list-style-type: none"> <li>● Replenish coolant</li> <li>● Adjust or replace fan belt</li> <li>● Replace fan belt</li> <li>● Repair or replace</li> <li>● Clean intercooler and water passages</li> <li>● Adjust ignition timing cor-rectly</li> <li>● Replace cylinder head gas-ket</li> </ul>
2. Lack of coolant	<ul style="list-style-type: none"> <li>● Intercooler leaky</li> <li>● Intercooler hoses loosely connected or damaged</li> <li>● Water pump leaky</li> <li>● Cylinder head gasket leaky</li> <li>● Cylinder head or cylinder block cracked</li> </ul>	<ul style="list-style-type: none"> <li>● Correct or replace</li> <li>● Retighten clamps or replace hoses</li> <li>● Repair or replace</li> <li>● Replace cylinder head gas-ket</li> <li>● Replace cylinder head or block</li> </ul>
3. Cooling system noisy	<ul style="list-style-type: none"> <li>● Water pump bearing defec-tive</li> </ul>	<ul style="list-style-type: none"> <li>● Replace bearing</li> </ul>

### 5.1.4. Thermostat

#### ● General descriptions and main data

The thermostat maintains a constant temperature of coolant (90 ~ 95°C) and improves thermal efficiency of the engine by preventing heat loss.


Namely, when the temperature of coolant is low, the thermostat valve is closed to make the coolant bypass to directly enter the water pump; when the coolant temperature rises to open wide the thermostat valve, the bypass circuit is closed and the water passage to the radiator is opened so that the coolant is forced to flow into the radiator.



Item	Specifications
Type	Wax-pallet type
Open at	79°C
Open wide at	94°C
Valve lift	8 mm or more

#### ● Inspecting

- (1) Check the wax pallet and spring for damage.
- (2) Put the thermostat in a container of water, then heat the water slowly and check temperature with a thermometer. If the valve lift is 0.1 mm (starting to open) at temperature of 79°C and 8 mm or more (opening wide) at temperature of 94°C, the thermostat is normal.



#### ● Replacing thermostat and precautions for handling

- (1) Precautions for handling

The wax pallet type thermostat does not react as quickly as bellows type one to a variation of temperature of coolant. Such relatively slow reaction is mainly due to the large heat capacity of the wax pellet type thermostat. Therefore, to avoid a sharp rise of coolant temperature, it is essential to idle the engine sufficiently before running it. In cold weather, do not run the engine at overload or overspeed it immediately after starting off.

- (2) When draining out or replenishing coolant, do it slowly so that air is bled sufficiently from the entire cooling system.
- (3) Replacing thermostat  
If the thermostat is detected defective, retrace with a new one.

### 5.1.5. Diagnostics and troubleshooting

Complaints	Possible causes	Corrections
1. Engine overheating	<ul style="list-style-type: none"> <li>● Lack of coolan</li> <li>● Radiator cap pressure valve spring weakened</li> <li>● Fan belt loosened or broken</li> <li>● Fan belt fouled with oil</li> <li>● Thermostat inoperative</li> <li>● Water pump defective</li> <li>● Restrictions in water passages due to deposit of scales</li> <li>● Injection timing incorrect</li> <li>● Restriction in radiator core</li> <li>● Gases leaking into water jacket due to broken cylinder head gasket</li> </ul>	<ul style="list-style-type: none"> <li>● Replenish coolant</li> <li>● Replace cap</li> <li>● Adjust or replace fan belt</li> <li>● Replace fan belt</li> <li>● Replace thermostat</li> <li>● Repair or replace</li> <li>● Clean radiator and water passages</li> <li>● Adjust injection timing correctly</li> <li>● Clean exterior of radiator</li> <li>● Replace cylinder head gasket</li> </ul>
2. Engine overcooling	<ul style="list-style-type: none"> <li>● Thermostat inoperative</li> <li>● Ambient temperature too low</li> </ul>	<ul style="list-style-type: none"> <li>● Replace thermostat</li> <li>● Install radiator curtain</li> </ul>
3. Lack of coolant	<ul style="list-style-type: none"> <li>● Radiator leaky</li> <li>● Radiator hoses loosely connected or damaged</li> <li>● Radiator cap valve spring weakened</li> <li>● Water pump leaky</li> <li>● Heater hoses loosely connected or broken</li> <li>● Cylinder head gasket leaky</li> <li>● Cylinder head or cylinder block cracked</li> </ul>	<ul style="list-style-type: none"> <li>● Correct or replace</li> <li>● Retighten clamps or replace hoses</li> <li>● Replace cap</li> <li>● Repair or replace</li> <li>● Tighten or replace hoses</li> <li>● Replace cylinder head gasket</li> <li>● Replace cylinder head block</li> </ul>
4. Cooling system noisy	<ul style="list-style-type: none"> <li>● Water pump bearing defective</li> <li>● Fan loosely fitted or bent</li> <li>● Fan out of balance</li> <li>● Fan belt defective</li> </ul>	<ul style="list-style-type: none"> <li>● Replace bearing</li> <li>● Retighten or replace fan</li> <li>● Replace fan</li> <li>● Replace fan belt</li> </ul>

## 5.2. Lubricating system

### 5.2.1. General descriptions and specifications


#### ● General descriptions

All the engine oil pumped up from the oil pan by the gear type oil pump is filtrated through the oil cooler and oil filter, and this filtrated oil is forced through the main oil gallery in the cylinder block from where it is distributed to lubricate the various sliding parts in order to ensure normal engine performance.

#### ● Specifications

Item	Specifications	Item	Specifications
Lubricating system	Forced pressure circulation	Oil filter type	Full flow
Oil pump type	Gear type	Bypass for filter element	Valve opening pressure
Relief valve opening pressure	$10 \pm 1.5 \text{ kg/cm}^2$	Bypass for entire oil filter	Valve opening pressure
Bypass for oil cooler	Opening pressure		
Opening pressure	$5 + 1 \text{ kg/cm}^2$		
Adjusting valve for spray nozzle	Opening pressure		
Opening pressure	$1.5 \sim 1.8 \text{ kg/cm}^2$		


#### ● Diagram of lubricating system




## 5.2.2. Oil pump

### ● Disassembly

- (1) Disassembly of oil pump drive gear
  - a. Unscrew the screw and disassemble the oil relief valve.
  - b. Unfold the washer for the oil pump drive gear fixing nut and remove the nut.
  - c. Disassemble the drive gear.



- (2) Remove the oil pump cover fixing nuts and disassemble the oil pump cover. The oil pump cover is fixed with the two dowel pins.




- (3) Disassemble the drive gear and driven gear.

### ● Inspection and correction


- (1) With steel rule and feeler gauge, measure the axial end play of the oil pump gear. Replace if the measured value is beyond the limit.

End play limit	0.025 ~ 0.089 mm
----------------	------------------



- (2) With a feeler gauge, measure the amount of backlash between the oil pump drive gear and driven gear. Replace if the measured value is beyond the limit.

Backlash limit	0.50 ~ 0.64 mm
----------------	----------------



(3) Measuring clearance between drive shaft and bushing

- a. Measure the outside diameters of the drive shaft and driven shaft, and replace if the measured values are less than the limit.

Standard	$\phi 16.95 \sim \phi 16.968 \text{ mm}$
----------	--

- b. Measure the inside diameter of the pump body bushing to determine the clearance between the bushing and shaft, and compare the measured value with the standard value to determine whether to replace or not.


Clearance	0.032 ~ 0.077 mm
-----------	------------------

#### ● Reassembly

- (1) For reassembly, reverse the disassembly sequence.

### 5.2.3. Oil filter

- The oil filter mounted in this engine is of cartridge type, so it is necessary to replace it with a new one at the specified intervals.



### 5.2.4. Diagnostics and troubleshooting

Complaints	Possible causes	Corrections
1. Oil consumption excessive	<ul style="list-style-type: none"> <li>● Poor oil</li> <li>● Oil seal or packing leaky</li> <li>● Pistons or piston rings worn</li>   <li>● Cylinder liner worn</li> <li>● Piston rings sticking</li>   <li>● Valve guide oil seals or valve guides, or valve stem worn</li> </ul>	<ul style="list-style-type: none"> <li>● Use suggested oil</li> <li>● Replace</li> <li>● Replace pistons and/or piston rings</li> <li>● Replace cylinder liner</li> <li>● Replace pistons and/or piston rings</li> <li>● Replace</li> </ul>
2. Oil pressure too low	<ul style="list-style-type: none"> <li>● Poor oil</li> <li>● Relief valve sticking</li> <li>● Restrictions in oil pump strainer</li> <li>● Oil pump gear worn</li> <li>● Oil pump feed pipe cracked</li> <li>● Oil pump defective</li> <li>● Oil pressure gauge defective</li> <li>● Various bearings worn</li> </ul>	<ul style="list-style-type: none"> <li>● Use suggested oil</li> <li>● Replace</li> <li>● Clean strainer</li>   <li>● Replace</li> <li>● Replace</li> <li>● Correct or replace</li> <li>● Correct or replace</li> <li>● Replace</li> </ul>
3. Oil deteriorates quickly	<ul style="list-style-type: none"> <li>● Restriction in oil filter</li> <li>● Gases leaking</li>   <li>● Wrong oil used</li> </ul>	<ul style="list-style-type: none"> <li>● Replace filter element</li> <li>● Replace piston rings and cylinder liner</li> <li>● Use suggested oil</li> </ul>

## 5.3. Turbocharger


### 5.3.1. Main data and specifications

#### 1) Main data and specifications

Specification		GE12TIC
Turbocharger model		HX50WG (HOLSET)
At maximum output	Air pressure at compressor outlet	Approx 0.8 kg/cm <sup>2</sup>
	Air suction volume	Approx 12.7 m <sup>3</sup> /min
	Speed of turbine revolution	Approx 80,000 rpm
Maximum allowable speed		110,000 rpm
Max. allowable temperature of exhaust gas at turbine inlet		750°C
Lubricating system		External oil supply
Weight		14 kg


#### 2) Operating principle

The turbocharger is a system designed to make use of the engine exhaust gas energy to charge high-density air into the cylinders, thereby to increase the engine output.



### 3) Construction

Make sure that servicing should be performed at the professional maintenance shop as authorized by HOLSET or HD Hyundai Infracore Company



EQM8026I

- |                    |                    |                        |
|--------------------|--------------------|------------------------|
| 1. Turbine housing | 15. Retainer ring  | 25. Bolt               |
| 2. Plug            | 16. Bearing        | 26. O-ring             |
| 5. Crank           | 17. Thrust collar  | 27. Compressor wheel   |
| 7. V-band          | 18. Screw          | 28. Nut                |
| 8. Wheel           | 19. Thrust bearing | 29. Bolt               |
| 9. Piston ring     | 20. Thrust space   | 30. Clamp              |
| 10. Wheel shroud   | 21. Piston ring    | 31. Compressor housing |
| 11. Center housing | 22. Seal ring      | 32. Elbow              |
| 12. Retainer ring  | 23. Seal ring      | 38. Retainer           |
| 13. Bearing        | 24. Rear plate     | 45. Bolt               |
| 14. Retainer ring  |                    |                        |

### 5.3.2. General descriptions

The engine output is determined by the fuel delivery volume and engine efficiency.

To burn the supplied fuel completely to change into effective power for the engine, the volume of air enough to burn the fuel completely should be supplied into the cylinders.

Therefore, the engine output is determined substantially by the cylinder capacity, and a greater volume of compressed air is charged into cylinders of given capacity, the greater engine output can be obtained as a greater volume of air charged into the cylinders burns so much more fuel.

As explained, the compressing of air to supply into the cylinders is called "Supercharging" and the making use of the energy of exhaust gas discharged from the combustion chamber to charge the compressed air into the cylinders is called "Turbocharging".

### 5.3.3. Functions

#### 1) Turbine

Exhaust gas discharged from the combustion chamber distributes its own energy to the turbine blades while passing the inside of the turbine housing, with the result that the turbine shaft can get rotating force. This is the operating principle of 'turbine', which is mounted with seal rings and heat protector to prevent exhaust gas from affecting the bearings adversely.

#### 2) Compressor

The compressor, which is connected to the turbine over the one and same shaft to form a rotating body, takes in and compresses ambient air with rotating force transmitted from the turbine shaft. Then, the compressed air is delivered to the intake stake. This is the operating principle of the compressor.

#### 3) Bearings

##### (1) Thrust bearing

The turbine wheel creates thrust force. Therefore, exercise care so that the shaft is not deviated from its the original position due to this thrust.

##### (2) Journal bearing

This journal bearing of floating type forms a dual oil film on both the inside and outside of the bearing so that the bearing can rotate independently. As the dual oil film plays a role as a damper, the sliding speed of the bearing surface becomes lower than the rotating speed of the shaft, resulting in assurance of stability in its movement.

#### 4) Sealing - Compressor shaft

The compressor is of a dual construction type composed of seal plate and seal ring to prevent the leak of compressed air or lubricating oil.

### 5.3.4. Precautions for operation

#### 1) Precautions for operation of engine

The following precautions should be observed when starting, operating, or stopping the engine:

Operations	Precautions	Reasons
When starting the engine	1) Check oil level 2) Crank the engine with starter to check the increase in oil pressure (until the needle of pressure gauge starts to move or pressure indicator lamp is actuated) before starting the engine.  3) When having replaced oil, oil filter element, or lubricating parts, or when having stopped the engine for extended period of time, or in a cold place, loosen the oil pipe connections and operate the starter motor until oil is discharged. After completing the operation, be sure to retighten the oil pipe connections portion before starting the engine.	2) Abrupt starting of the engine causes the engine to rotate with oil not being distributed not only to each part but also to the turbocharger, resulting in abnormal wear or seizure on the bearing due to insufficient supply of oil.  3) In the case of the engine stopped for extended time or in a cold place, oil fluidity within the pipes can be deteriorated
Immediately after starting	1) Run the engine at idle for 5 minutes after starting off.  2) Check each part for leakage of oil, gas, and air, and take proper measure.	1) Applying load abruptly If load is abruptly applied with the engine and turbocharger rotating unsmoothly, such parts that a sufficient amount of oil has not reached can be seized up.  2) Leakage of oil, gas, and air (especially, oil leak) causes drop in oil pressure and loss of oil results in seizure of the bearing.
During operation	Check the followings: 1) Oil pressure At idle: 0.8 kg/cm <sup>2</sup> or more At full load: 3.0 ~ 4.8 kg/cm <sup>2</sup>  2) If unusual sound or vibration is heard or felt, reduce engine revolutions slowly and locate the cause.	1) Excessively low oil pressure causes unusual wear or seizure of the bearing. Too high pressure causes oil leakage.  2) The engine is operated continuously with unusual sound or vibration not corrected, it can be damaged beyond repair.
When stopping the engine	1) Run the engine at idle for 5 minutes before stopping.	1) If the engine is put to a stop after being operated at high load, heat from the red-hot turbine blades is transmitted to the bearing portion and burns oil to cause seizure of the bearing metal and rotating shaft.

### 5.3.5. Walk-around check and servicing

As the condition of turbocharger depends greatly on how well the engine is serviced, it is very important to maintain the engine in accordance with the specified maintenance procedure.

#### 1) Intake system

Pay particular attention to the air cleaner when servicing the intake system.

In the case of wet-type air cleaner, if the level of oil surface is lower than specified, cleaning effect is poor; if too high, the cleaner draws in oil to foul the case.

Especially, if the rotor is fouled, the sophisticatedly-tuned balance is broken to create vibration and to cause seizure and unusual wear to the bearing.

Therefore, it is very important to use a good quality air cleaner all the time.

In the case of dry-type air cleaner, it is essential to clean it to reduce intake resistance as much as possible.

#### 2) Exhaust system

Pay particular attention to prevent gas leaks and seizure when servicing the exhaust system because leakage of exhaust gas from discharge pipes, turbocharger fixing portions, etc. lowers charging effect.

As such components as turbine chamber that becomes red-hot during operation use heat resisting steel nuts, do not interchange these nuts with ordinary steel nuts. In addition, apply anti-seizure coating to fixing nuts on the portions as designated.

#### 3) Lubricating system

Pay particular attention to oil quality and oil filter change intervals when servicing the lubricating system. Deteriorated engine oil affects adversely not only the engine but also the turbocharger. Suggested engine oils for the turbocharger-mounted engine are as follows:

Engine model	Recommend oil		Sulfated ash content
	SAE No.	API No.	
GE12TIC	SAE 15W40	CD/SF or later	Bellow 0.5 %

### 5.3.6. Periodical checking and servicing

Make it a rule to check the turbocharger assembly for condition and contamination periodically.

#### 1) Guide for checking the rotor for rotating condition

The inspection of the rotor assembly for rotating condition should be performed by the degree of unusual sound. If a sound detecting bar is used, install its tip on the turbocharger housing and increase the engine revolutions slowly. If a high-pitch sound is heard continuously, it means that the rotor assembly is not normal. In this case, as the metal bearing and rotor are likely to be in abnormal conditions, the turbocharger should be replaced or repaired.

#### 2) Guide for checking rotor end play

Disassemble the turbocharger from the engine, then check the rotor axial play and radial play. When disassembling the turbocharger, be sure to plug the oil inlet and outlet ports with taps, etc.

#### 2) Guide for checking rotor end play

Disassemble the turbocharger from the engine, then check the rotor axial play and radial play. When disassembling the turbocharger, be sure to plug the oil inlet and outlet ports with taps, etc.

#### 3) Special hints


It is recommended that the radial and axial clearances of the rotor be checked after every 3,000 hours operation.

This precaution will enable any wear of the Measuring of axial clearance bearings to be detected in good time before serious damage is caused to the rotor and bearings.

##### (a) Rotor axial play

- Measuring rotor axial clearance


Axial clearance	0.2 mm
-----------------	--------



(b) **Rotor radial play**

- Measuring radial clearance

Radial clearance	0.65 mm
------------------	---------



(c) If the measured axial and radial plays are beyond the limit of wear, replace or repair the turbocharger.

**4) Guide for disassembling/cleaning and checking the turbocharger**

First, disassemble the turbocharger from the engine and clean/check it with the oil inlet and outlet plugged with tape and so on.

**5) Precautions for reassembling the turbocharger onto the engine**

For reassembly of the turbocharger or handling it after reassembly operation, be sure to observe the following precautions:

Especially, exercise extreme care to prevent foreign matters from entering the inside of the turbocharger.

(a) **Lubricating system**

- Before reassembling the turbocharger onto the engine, inject new oil in the oil inlet port and lubricate the journal and thrust bearings by rotating them with hand.
- Clean not only the pipes installed between the engine and oil inlet port but also the oil outlet pipe and check them for damage or foreign matters.
- Assemble each joint on oil pipes securely to prevent oil leaks.

(b) **Intake system**

- Check the inside of the intake system for foreign matters.
- Assemble each joint on the intake duct and air cleaner securely to prevent air leaks.

(c) **Exhaust system**

- Check the inside of the exhaust system for foreign matters.
- Be sure to use heat resisting steel bolts and nuts. Do not interchange them with ordinary steel bolts and nuts when performing reassembly operation. Apply anti-seizure coating to the bolts and nuts.
- Assemble each joint on the exhaust pipes securely to prevent gas leaks.

**5.3.7. Diagnostics and troubleshooting**

<b>Complaints</b>	<b>Possible causes</b>	<b>Corrections</b>
1. Excessive black smoke	1) Air cleaner element clogged 2) Restrictions in air duct 3) Leakage at intake manifold 4) Turbocharger seized up and not rotating 5) Turbine blades and compressor blades coming in contact with each other or damaged 6) Exhaust piping deformed or clogged	Replace or clean Check and correct Check and correct Disassemble/repair or replace Disassemble/repair or replace Check and correct
2. Excessive white smoke	1) Oil leak into turbine and compressor 2) Worn or damaged seal ring due to excessive wear of bearing	Disassemble/repair or replace Disassemble/repair or replace
3. Low engine output	1) Gas leak at each part of exhaust system 2) Air cleaner element restricted 3) Turbocharger fouled or damaged 4) Leakage at discharge port on compressor side	Check and correct Replace or clean Disassemble/repair or replace Check and correct
4. Unusual sound or vibration	1) Rotor assembly coming in contact 2) Unbalanced rotation of rotor 3) Seized up 4) Each joint loosened	Disassemble/repair or replace Disassemble/repair or replace Disassemble/repair or replace Check and correct

## 5.4. Air intake system (Optional)

### 5.4.1. Maintenance


(only when engine is switched off)

Empty the dust bowl (7) regularly. The bowl should never be filled more than halfway with dust.

On slipping off the two clamps (3), the dust bowl can be removed. Take off the cover (6) of the dust bowl and empty.

Be careful to assemble cover and bowl correctly.

There is a recess in the cover rim and a lug on the collector which should register. Where the filter is installed horizontally, watch for "top" mark on cleaner bowl.




### 5.4.2. Changing filter element

- On removing the hexagon nut, take out the dirty cartridge and renew or clean.
- Wipe the cleaner housing with a damp cloth, in particular the sealing surface for the element.



**NOTE:**


**Do not allow dirt to get into the clean air end.**



### 5.4.3. Cleaning filter elements


#### ● By compressed air (wear goggles)

- For the purpose, the air gun should be fitted with a nozzle extension which is bent 90° at the discharge end and which is long enough to reach down inside to the bottom of the element.
- Moving the air gun up and down, blow out the element from the inside (maximum 500kPa - 5 bar) until no more dust comes out of the filter pleats.



#### ● By washing

- Before washing, the element should be precleaned by means of compressed air, as described above.
- Then allow the element to soak in luke-warm washing solvent for 10 minutes, and then move it to and for in the solvent for about 5 minutes.
- Rinse thoroughly in clean water, shake out and allow drying at room temperature. The cartridge must be dry before it is reinstalled.
- Never use steam sprayers, petrol (gasoline), alkalis or hot liquids etc. to clean the filter elements.




#### ● Knocking out dirt by hand

- In emergencies, when no compressed air or cleaning agent is available, it is possible to clean the filter cartridge provisionally by hitting the end disk of the cartridge with the ball of one's thumb.
- Under no circumstances should the element be hit with a hard object or knocked against a hard surface to loosen dirt deposits.

● **Checking the filter cartridge**

- Before reinstalling the cartridge, it must be checked for damage e.g. to the paper pleats and rubber gaskets, or for bulges and dents etc. in the metal jacket.
- Cracks and holes in the paper pleating can be established by inspecting the cartridge with a flashlight.
- Damaged cartridges should not be re-used under any circumstances. In cases of doubt, discard the cartridge and install a new one.



## Appendix

### ● Tightening torque for major parts

Major Parts		Screw	Strength	Tightening Torque
Cylinder Block	Main Bearing Cap Bolt	M16 x 1.5	12.9T	30 kgf.m
Oil Spray Nozzle		M6 x 1	8.8T	1.0 ±0.1 kgf.m
Flywheel Housing Bolt		M12 x 1.5	10.9T	11.2 ±1.6 kgf.m
Damper Pulley		M12 x 1.5	12.9T	13.4 ±1.3 kgf.m
Conrod Bearing Bolt		M16 x 1.5	12.9T	1st: 8 ±0.4 kgf.m 2nd: 60° ±3°
Flywheel Bolt		M14 x 1.5	10.9T	20 ±3.6 kgf.m
Head Bolt		M14 x 1.5	110 ~ 118 kg/mm <sup>2</sup>	6 ±0.6 kgf.m → 90° ±9° → 90° ±9° → 90° ±9°
Head Cover Bolt		M8 x 1.25	10.9T	3.1 ± 0.3 kgf.m
EX Manifold Bolt		M10 x 1.5 M12 x 1.5	8.8T	4.4 ±0.44 kgf.m 8.0 ±0.8 kgf.m
Intake Manifold Bolt		M10 x 1.5	8.8T	4.4 ±0.44 kgf.m
Idle Gear Pin Bolt		M10 x 1.5	12.9T	7.4 ±0.7 kgf.m
Oil Pump		M10 x 1.5	8.8T	4.4 ±1.1 kgf.m
Relief Valve		M22 x 1.5	SUM22	9.0 ±2.3 kgf.m
Oil Pan		M8 x 1.25	10.9T	3.1 ±0.31 kgf.m
Oil Cooler		M8 x 1.25	8.8T	2.2 ±0.22 kgf.m
Water Pump		M10 x 1.5	10.9T	6.2 ±1.55 kgf.m
Starter		M10 x 1.5 (Nut)	10.9T	6.2 ±1.55 kgf.m
Rocker Arm Bolt		Ⓐ M10 x 1.5 Ⓑ M8 x 1.25	Ⓐ 10.9T Ⓑ 8.8T	6.2 ±0.62 kgf.m 2.2 ±0.22 kgf.m
Cooling Water Pipe		M8 x 1.25	8.8T	2.2 ±0.22 kgf.m
Alternator		M12 x 1.5	8.8T	8 ±2 kgf.m

### ● Tightening torque for plug screw

Diameter x pitch	M10x1.0	M12x1.5	M14x1.5	M16x1.5	M18x1.5	M22x1.5	M26x1.5	M30x1.5
Torque (kg.m)	5.0	5.0	8.0	8.0	10.0	12.0	12.0	15.0

### ● Tightening torque for hollow screw(4-hole)

Material	M8	M10	M12	M14	M16	M18	M22	M26	M30	M38
SM25C	-	1.6	2.5	3.5	4.5	5.5	9.0	13.0	18.0	30.0
* SUM22L	0.8	1.8	3.0	4.0	5.5	6.5	11.0	16.0	20.0	35.0
STS304	0.8	1.8	3.0	4.0	5.5	6.5	11.0	16.0	20.0	35.0

\* : Adopted in HD Hyundai Infracore engine

● **Standard bolt tightening torque table**

Refer to the following table for bolts other then described above

Diameter x pitch (mm)	Degree of strength										
	3.6	4.6	4.8	5.6	5.8	6.6	6.8	6.9	8.8	10.9	12.9
	(4A)	(4D)	(4S)	(5D)	(5S)	(6D)	(6S)	(6G)	(8G)	(10K)	(12K)
	Limit value for elasticity (kg/mm <sup>2</sup> )										
	20	24	32	30	40	36	48	54	64	90	108
Tightening torque (kg.m)											
M5	0.15	0.16	0.25	0.22	0.31	0.28	0.43	0.48	0.5	0.75	0.9
M6	0.28	0.30	0.45	0.4	0.55	0.47	0.77	0.85	0.9	1.25	1.5
M7	0.43	0.46	0.7	0.63	0.83	0.78	1.2	1.3	1.4	1.95	2.35
M8	0.7	0.75	1.1	1	1.4	1.25	1.9	2.1	2.2	3.1	3.8
M8x1	0.73	0.8	1.2	1.1	1.5	1.34	2.1	2.3	2.4	3.35	4.1
M10	1.36	1.4	2.2	1.9	2.7	2.35	3.7	4.2	4.4	6.2	7.4
M10x1	1.5	1.6	2.5	2.1	3.1	2.8	4.3	4.9	5	7	8.4
M12	2.4	2.5	3.7	3.3	4.7	4.2	6.3	7.2	7.5	10.5	12.5
M12x1.5	2.55	2.7	4	3.5	5	4.6	6.8	7.7	8	11.2	13.4
M14	3.7	3.9	6	5.2	7.5	7	10	11.5	12	17	20
M14x1.5	4.1	4.3	6.6	5.7	8.3	7.5	11.1	12.5	13	18.5	22
M16	5.6	6	9	8	11.5	10.5	17.9	18.5	18	26	31
M16x1.5	6.2	6.5	9.7	8.6	12.5	11.3	17	19.5	20	28	33
M18	7.8	8.3	12.5	11	16	14.5	21	24.2	25	36	43
M18x1.5	9.1	9.5	14.5	12.5	18.5	16.7	24.5	27.5	28	41	49
M20	11.5	12	18	16	22	19	31.5	35	36	51	60
M20x1.5	12.8	13.5	20.5	18	25	22.5	35	39.5	41	58	68
M22	15.5	16	24.5	21	30	26	42	46	49	67	75
M22x1.5	17	18.5	28	24	34	29	47	52	56	75	85
M24	20.5	21.5	33	27	40	34	55	58	63	82	92
M24x1.5	23	25	37	31	45	38	61	67	74	93	103

**Others :**

1. The above torque rating have been determined to 70% or so of the limit value for bolt elasticity.
2. Tension is calculated by multiplying tensile strength by cross section of thread.
3. Special screws should be tightened to 85% or so of the standard value.

For example, a screw coated with MoS<sub>2</sub> should be tightened to 60% or so of the standard value.

● Maintenance specification table

(Unit : mm)

Group	Part	Check	Stand value for assembly	Limit for use	Correction	Remark	
Engine body	Cylinder block & liner	Inside diameter of cylinder liner for wear	$\phi 123 \sim \phi 123.023$	$\phi 123.223$	Replace liner	Measure unworn portion beneath the rim of the upper side	
		Projected portion of liner	0.03 ~ 0.08	-			
		The upper surface of cylinder block of distortion	0.05	-	Correct with a surface grinder	Per distortion length for 200mm	
		Hydraulic test for 1 minute (kg/cm <sup>2</sup> )	4	-			
	Cylinder head & valve	Valve seat depression	Intake	0 ~ 0.3	0.55		
			Exhaust	0 ~ 0.3	0.55		
		height	114.95 ~ 115	113.9	Replace cylinder head		
	Hydraulic test for 1 minute (kg/cm <sup>2</sup> )	4	-	Replace if leaky	Water temperature 70°C		
Major moving parts	Piston	Piston diameter (18mm from the lower side)	$\phi 122.854 \sim \phi 122.886$	-			
		Clearance between piston and liner	0.114~0.169	-			
		Width of piston ring grooves	Top ring	3.5	-	Replace piston if groove width is beyond specified value	
			2nd ring	3.060 ~ 3.080	-		
			Oil ring	4.040 ~ 4.060	-		
		Piston projection from cylinder block upper surface	0 ~ 0.12	-		Measure unworn portion beneath the rim of upper side	
		Permissible weight difference of each piston	$\pm 15$ g	96g			
	Piston ring	Piston ring gap	Top ring	0.30 ~ 0.45	1.5		Standard gauge inside diameter : $\phi 123$
			2nd ring	0.35 ~ 0.50	1.5		
			Oil ring	0.30 ~ 0.50	1.5		
		Piston ring side clearance	Top ring	-	-	Replace ring or piston	Limit for use if for standard clearance
			2nd ring	0.07 ~ 0.102	0.15		
			Oil ring	0.05 ~ 0.085	0.15		
Direction of ring gap	-	-	Install ring by 120°				

(Unit : mm)

Group	Part	Inspection Item	Stand value for assembly	Limit for use	Correction	Remark
Major moving parts	Crank shaft	Axial run-out of journal and pin	0.05	0.1	Correct with a grinder	In horizontal and vertical directions
		Outside diameter of journal	$\phi 95.966 \sim \phi 95.988$	$\phi 94.966$	Replace crankshaft	$\phi 96$ g6
		Outside diameter of pin	$\phi 82.966 \sim \phi 82.988$	$\phi 81.966$	Replace crankshaft	$\phi 83$ g6
		Permissible radial run out of journal and pin	0.008	0.025		
		Permissible taper of journal and pin	0.01	0.03		
		Clearance between crankshaft and bearing	0.01	0.03		
		Clearance between crankshaft and bearing	0.072 ~ 0.142	0.25	Replace bearings	Measure in the position of crown
		End play of crankshaft	0.15 ~ 0.325	0.5	Replace thrust bearing	
		Run-out of crankshaft	0.05	0.1 or less	Adjust by a press if bent	No.4 bearing (holding no. 1 & 7)
		Balance of crankshaft	60	60 or less	Check dynamic balance	Measure at 400 rpm
		Tightening torque of journal bearing cap bolt (kg.m)	30	-	Apply oil to bolt	No foreign, matters on bearing cap installing surface
		Journal bearing crush	0.15 ~ 0.25	-		Measure by tightening metal cap & then loosening one stud bolt
		Oil seal for wear	-	-	Replace oil seal if oil leaking	Replace with new one, use shim
	Connecting rod	Clearance between con-rod bearing & crank pin	0.049 ~ 0.119	0.20	Replace bearing	
		End play of con-rod crush	0.22 ~ 0.319	0.5	Replace con-rod	
		Clearance between small end bush & piston pin	0.050 ~ 0.080	0.12		
		Con-rod bearing crush height	0.086 ~ 0.116	-		After completing of bearing loosen one stud bolt & measure
		Permissible weight difference of each con-rod	$\pm 18$ g	-		
		Tightening torque of con-rod bearing cap bolt (kg.m)	28	-	Apply oil to bolt	

(Unit : mm)

Group	Part	Inspection Item	Stand value for assembly	Limit for use	Correction	Remark	
Major moving parts	Cam shaft	Outside diameter of camshaft	$\phi 59.860$ ~ $\phi 59.880$	$\phi 59.52$		$\phi 60$	
		Clearance between camshaft and bush	0.050 ~ 0.128	0.20			
		Axial play of camshaft	0.13 ~ 0.27	0.30	Replace thrust plate		
	Timing gear	Clearance between idle gear shaft and inserting hole	0.025 ~ 0.091	0.15			
		End play of idle gear shaft	0.043 ~ 0.167	0.3	Replace thrust collar		
		Between crank gear & idle gear	0.10 ~ 0.20	-	Replace gear		
		Between idle gear & camshaft gear	0.10 ~ 0.20	-			
Valve system	Valve	Outside diameter of intake valve stem	$\phi 10.950$ ~ $\phi 10.970$	$\phi 10.87$	Replace valve & guide	Replace valve guide together when replacing valve	
		Outside diameter of exhaust valve stem	$\phi 10.935$ ~ $\phi 10.955$	$\phi 10.84$			
		Clearance between valve stem and valve guide	Intake	0.030 ~ 0.065	0.15	Replace	
			Exhaust	0.045 ~ 0.080	0.18		
		Thickness of valve	Intake	1.5	1 or more	Replace	
			Exhaust	1.5	0.9 or more		
		Perm. radial run-out between valve stem & valve head	Intake	0.04 ~ 0.07	0.2	Replace	
			Exhaust	0.04 ~ 0.07	0.25		
		Clearance between valve guide & cylinder head installing hole		0.01 ~ 0.39	-		Apply oil to valve guide & press in
		Clearance between valve guide & valve spring seat	Intake	22	-		
Exhaust	22		-				

(Unit : mm)

Group	Part	Inspection Item	Stand value for assembly	Limit for use	Correction	Remark		
Valve system	Valve	Intake spring	Free length	75.5	72			
			Spring tension (set length : 37mm) kg	61.8 ~ 68.3	61.8			
			Straightness (against free length)	1.0	2.0			
		Exhaust valve spring	Inner	Free length	65	61.75		
				Spring tension (set length : 34mm) kg	36.1 ~ 39.9	36.1	Replace valve spring	
				Straightness (against free length)	1.0	2.0		
			Outer	Free length	75.5	72		
				Spring tension (set length : 37mm) kg	61.8 ~ 68.3	61.8	Replace valve spring	
				Straightness (against free length)	1.0	2.0		
		Valve clearance (at cold)	Intake	0.4 ±0.05	-	Adjust		
			Exhaust	0.4 ±0.05	-			
		Contacting face of valve stem & rocker arm			-	-	Correct or replace if severely pitted on tip of arm and stem	
		Clearance between rocker arm shaft & rocker arm bush			0.020 ~ 0.093	0.2	Replace bush or shaft	
		Rocker arm shaft for wear			φ 23.978 ~ φ 23.959	φ 23.75	Replace	
	Permissible taper of push rod			0.3	-	Replace		
	Tappet	Clearance between tappet & cyl. block		0.035 ~ 0.077	0.15	Replace tappet		
		Outside diameter of tappet		φ 19.944 ~ φ 19.965	-	Replace tappet		
Contacting face of tappet & cam		-	-	Replace if excessively worn or deformed				


(Unit : mm)

Group	Part	Inspection Item	Stand value for assembly	Limit for use	Correction	Remark	
Lubricating system	Oil pressure	Oil pressure(normal speed) kg/cm <sup>2</sup>	4.5 or less	3.5	Correct oil leakage and clearance between each part		
		Oil pressure(idling) kg/cm <sup>2</sup>	0.8 ~ 1.4	0.6	Use suggested oil		
	Oil temperature	Max. permissible oil temperature °C	-	105		Temperature above this not allowable	
		Permissible oil temperature in short time °C	-	120			
	Oil pump	Axial play of oil pump gear		0.055 ~ 0.105	-	Replace gear or cover	
		Clearance between gear shaft & oil pump cover hole		0.032 ~ 0.068	-		
		Clearance between drive gear shaft & cover hole		0.040 ~ 0.082	-	Replace bushing or cover	
		Outside diameter of gear shaft		φ 16.950 ~ φ 16.968	-	Replace gear	φ 17e7
		Outside diameter of drive gear bushing		φ 27.939 ~ φ 27.960	-	Replace bushing	φ 28e7
		Backlash	Between crank gear & oil pump drive gear	0.15 ~ 0.25	0.8	Adjust back-lash	
	Between oil pump drive gear & intermediate gear		0.15 ~ 0.25	0.8			
	Valve opening pressure	Oil pressure control valve (kg/cm <sup>2</sup> )		4.3 ~ 4.7	-	Replace valve	
		By-pass valve for filter element (kg/cm <sup>2</sup> )		1.8 ~ 2.3	-		
		By-pass valve for full oil filter (kg/cm <sup>2</sup> )		4.0 ~ 4.8	-		
		By-pass valve for oil cooler (kg/cm <sup>2</sup> )		5 ~ 6	-		
		Relief valve for oil pump (kg/cm <sup>2</sup> )		8.5 ~ 11.5	-		
		Control valve for spray nozzle (kg/cm <sup>2</sup> )		1.5 ~ 1.8	-		
Oil filter	Oil filter element for damage		-	-	Clean or replace		

(Unit : mm)


Group	Part	Inspection Item	Stand value for assembly	Limit for use	Correction	Remark
Cooling system	Radiator	Radiator & water pump for corrosion, damage & improper connecting	-	-	Correct or replace	
		Test for leakage (air pressure) (kg/cm <sup>2</sup> )	1.5	-	Submerge in water and replace if air bubbles found	
		Pressure valve for opening pressure (kg/cm <sup>2</sup> )	0.5	-		
		Negative pressure valve for opening pressure (kg/cm <sup>2</sup> )	0.2	-		
	Water pump	Delivery volume l/min - Engine speed 1,800rpm - Water temp. 24°C - Back pressure : 1 kg/cm <sup>2</sup>	Approx. 350	-		
		Clearance between pump impeller & pump body	0.3 ~ 0.6	-	Replace if contacted impeller & pump body	
	Cooling water temp	Operating temperature(permissible temp.) °C	90 ~ 95	95	Temperature above this not allowable	
		Permissible temperature in a short time °C	103	103		
	Thermostat	Thermostat opening temp. °C (under atmospheric pressure)	83	-	Replace if defective	
		Full operating temp. °C	95 or lower	-		Stroke : min. 8 mm
Ignition system	Spark plug	Gap of spark plug	0.39 ~ 0.40	-	Correct or replace	
Inspection at completion	Running-in the engine		-	-	Refer to supplement "running-in"	Retighten head bolt after running in
	Cylinder pressure	Cylinder compression pressure of cylinder (kg/cm <sup>2</sup> )	18	15 or more	Overhaul the engine	
		Compression pressure difference of each cylinder	±10% or less against average	-	Correct	at 200rpm or more (20°C)

● Engine Assembly (GE12TIC : EEIOD)



EF5OM035

● Engine Assembly (GE12TIC : Optional - large volume oil pan)



EF5OM036